

The Most Trusted Name in the Kitchen®

Cuisinart®

Use and Care

Hand-wash cutlery for best results.

To clean cutlery block surface, wipe with a warm, wet cloth/sponge and towel-dry immediately. **Do not immerse in water.**

Lifetime Warranty (U.S. and Canada ONLY)

Cuisinart® Cutlery is warranted to be free of defects in material and workmanship under normal home use from the date of original purchase throughout the original purchaser's lifetime. If your cutlery should prove to be defective within your lifetime, we will replace it without charge to you, except for shipping and handling. To obtain warranty service, please call our Consumer Service Center toll-free at 1-800-726-0190, or write to Consumer Service Center, Cuisinart, 150 Milford Road, East Windsor, NJ 08520. To facilitate the speed and accuracy of your return, please enclose \$5.00 for shipping and handling of the product. Be sure to include a return address, description of the product problem, phone number, and any other information pertinent to the product's return. Please pay by check or money order made payable to Cuisinart. This warranty excludes damage caused by accident, misuse or abuse, including damage caused by overheating, and it does not apply to scratches, stains, discoloration or other damage to external surfaces that does not impair the functional utility of the cutlery. This warranty also expressly excludes all incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the foregoing limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

California Residents Only

California residents should call 1-800-726-0190 for shipping instructions. Cuisinart will be responsible for the cost of the repair, replacement, and shipping and handling of such nonconforming products under warranty.

© 2017 Cuisinart
150 Milford Road, East Windsor, NJ 08520
Visit our website: www.cuisinart.com
Made in China
16CK022875



Follow us @Cuisinart