

Explanation of terms

"Maximum Wind Resistance" and "Maximum Roof Load"

Wind and roof capacities given are for reference only and assume a securely anchored frame according to local building codes and ordinances. These have been calculated using combined snow and wind load provisions in accordance with ASCE 7-05. The snow load provisions have been used to determine the equally distributed roof load capacities noted. These calculations are based on an unoccupied, fully enclosed building, properly assembled and maintained, with no unauthorized customer modifications. Local building code requirements vary by location; conformance to local codes is the responsibility of the purchaser.

