


## Indoor Comfort Level Station



DRY	< 34%
DRY/COMFORT	35 - 40%
COMFORT	41 - 55%
COMFORT/WET	56 - 64%
WET	> 65%

The arrow marks current ambient humidity on the display from 'DRY' to 'WET'

**Note:** the arrow will not be shown if the temperature is overflow ("OF.L")

## Get Started

**Step 1:** Insert 1 x AAA, IEC LR3, 1.5V Alkaline battery according to polarity. The indoor temperature, humidity data, and the comfort level indicator will be displayed.

**Note:** This station does not have a battery cover.

**Restart:** If the indoor temperature is not displayed after 60 seconds, remove batteries from the comfort station. Press any button 20 times. After 15 minutes, return to **Step 1** above.

## MIN/MAX Button

- Press to view the MIN/MAX temperature and humidity records.
- Hold 3 seconds to reset the MIN/MAX temperature records

## Fahrenheit/Celsius (°C/°F Button)

- Toggle between °C and °F temperature readings.

## Low Battery Icon

- Replace the battery when the battery icon appears.



## Specifications

**Temperature:** 32°F to 122°F with 0.2°F resolution 0°C to 50°C with 0.1°C Resolution ("O.F.L" displayed if outside this range)

**Humidity:** 20% - 95% RH ("19%" will be displayed if the reading is lower than 20%; 96%" will be displayed if the reading is higher than 95%)

**Interval:** every 20 seconds (or every 2 minutes if the low battery icon is shown)

**Battery:** 1 x AAA, IEC LR3, 1.5V

**Battery life:** approximately 12 months

**Dimensions:** (L x W x H): 3.46" x 0.64" x 3.42" (88 x 16,5 x 86,9mm)

## Care and Maintenance

- **Do not mix old and new batteries**
- **Do not mix Alkaline, Standard, Lithium or Rechargeable Batteries**
- Always purchase the correct size and grade of battery most suitable for intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed with correct polarity (+ and -).
- Remove batteries from equipment which is not to be used for an extended time.
- Remove expired batteries promptly.

## Warranty and Support Information

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

**View full warranty details online at:**

[www.lacrossetechnology.com/warranty\\_info.pdf](http://www.lacrossetechnology.com/warranty_info.pdf)



**For warranty work, technical support or other information contact:**

La Crosse Technology, Ltd  
2830 26<sup>th</sup> Street S.  
La Crosse, WI 54601

**Contact Support:**

1-608-782-1610

**Online Product Support:**

[www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)

**Product Registration:**

[www.lacrossetechnology.com/support/register](http://www.lacrossetechnology.com/support/register)