

4-Person Pop-Up Tent Instructions

Assembly

- . Unpack the tent and remove the strap. Pull both sides outward gently—the tent pops open automatically. No pole assembly needed.
- . Place on flat ground. Hammer 8 tent pegs through the loops at the base (45° angle to the ground). Attach 4 wind ropes to the tent's anchors, secure the other ends with pegs, and tighten for stability.

Usage

- Mesh doors: Close for ventilation.
- Nylon curtains: Pull up to seal when raining (operate from inside).
- Vestibule: Store muddy shoes/outerwear to keep the main area clean.
- Use internal storage pockets and lantern hook for organization.

Disassembly

- . Remove pegs and wind ropes first.
- . Press the top, fold sides inward, roll into a cylinder, fasten with the strap, and pack into the bag.