

Use and Care Manual

Use and Care Manual: Wicker Egg Chair

Thank you for choosing our Wicker Egg Chair. Please read and follow these instructions carefully to ensure optimal use and longevity of your chair.

Assembly Instructions:

1. Carefully unpack all parts and lay them out in a clear area.
2. Assemble the steel frame according to the provided instructions. Use the included hardware and tools as necessary.
3. Attach the wicker seat shell to the frame securely.
4. Install the cushions onto the seat and backrest, ensuring they are properly aligned and securely fastened.

Use Instructions:

1. Place the assembled chair in your desired location, whether indoors or outdoors.
2. Ensure that the chair is placed on a stable and level surface.
3. To maximize comfort, adjust the position of the cushions as needed.
4. Do not exceed the maximum weight capacity of 440lbs.

5. Avoid placing sharp objects or heavy items on the chair, as this may cause damage.
6. When not in use, consider covering the chair with a suitable protective cover to prolong its lifespan.

Care Instructions:

1. Regularly inspect the chair for any signs of damage or wear.
2. Clean the wicker seat shell and steel frame regularly with a mild detergent and water solution. Avoid using harsh chemicals or abrasive cleaners.
3. Remove any stains or spills from the cushions promptly to prevent permanent damage. Spot clean with a mild soap and water solution.
4. Ensure the chair is completely dry before storing or covering it to prevent mold or mildew growth.
5. Store the chair indoors or in a covered area during inclement weather to prevent damage from exposure to the elements.

Maintenance Tips:

1. Tighten any loose bolts or screws periodically to ensure the stability of the chair.

2. Inspect the cushions for any signs of wear or deterioration and replace them as needed.
3. Avoid dragging the chair across rough surfaces, as this may cause damage to the wicker or frame.
4. Periodically apply a protective coating or sealant to the wicker and steel frame to prolong their lifespan and enhance their appearance.

Safety Precautions:

1. Always use the chair as intended and follow the weight capacity guidelines.
2. Keep children and pets away from the chair when it is in use.
3. Do not attempt to modify or alter the chair in any way, as this may compromise its structural integrity and safety.

By following these guidelines, you can enjoy years of use and enjoyment from your Wicker Egg Chair. If you have any questions or concerns, please contact our customer service team for assistance.