USE AND CARE GUIDE



Questions, problems, missing parts? Before returning to the store, call Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday

1-877-527-0313

HAMPTONBAY.COM

THANK YOU

Warranty

WARRANTY

WHAT IS COVERED

This product is covered under a 1 year limited warranty against defects in materials and workmanship from the date of purchase.

WHAT IS NOT COVERED

This warranty does not cover damage due to neglect, abuse, or weather related damage.

Contact the Customer Service Team at 1-877-527-0313 or visit www. Homedepot.com.

Care and Cleaning

- □ Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol-based cleaners.
- Rinse with clean water and dry with a soft, absorbent cloth towel.



Questions, problems, missing parts? Before returning to the store, call Home Depot Customer Service 8 a.m. - 7 p.m., EST, Monday-Friday

1-877-527-0313

HOMEDEPOT.COM

Retain this manual for future use.