



Sling Stacking Chair

Use and Care Guide

ITEM # 378 759 121 891 121 901 121 886 121 887

MODEL # FCS00015J FCS00015J-DBS FCS00015J-RED FCS00015J-COR FCS00015J-PCK

Operation

Using the Chair

□ Always place the chair on a hard, level suface.



WARNING: Do not rock in the chair as you may fall and cause serious injury.

Care and Cleaning

- □ For best results, clean the frame with damp cloth, and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- $\hfill\square$ Do not clean with abrasive materials, bleach or solvents.
- □ Store the chair in a dry, sheltered place when not in use.
- □ Keep the chair out of fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

Warranty

2 YEAR WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for two years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center.

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For questions or concerns about this product, contact the Customer Service Team 8 a.m. - 7 p.m., EST, Monday through Friday 9 a.m. - 6 p.m., EST, Saturday at 01-800-00-46633 or visit Homedepot.com.mx.

