



















## Care & Maintenance

-   ☒ Do not put hot items directly on furniture surface.
-   ☒ Do not clean furniture with harsh cleansers or polish.
-   ☒ To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
-   ☒ Children should not climb or jump on the furniture.
-   ☒ Do not write on furniture without a padded barrier to protect the surface.
-   ☒ To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
-   ☒ Not for commercial use. For residential use only
-   ☒ Stains may be removed with mild soap solution and damp cloth.
-   ☒ Dust and pick-up spills using a clean, non-colored, lint-free cloth.