

1. Model: RV001

Weight: 5 ounces

Requires 2 AA Batteries (Not Included)

Voltage: DC 3.0 V (AAUM3 1.5V battery a pair)

2. Uses For Product:

1. To remove light debris from desks and tables
2. To remove hair or dust from garments
3. To remove dust from home appliances, computer keyboards, or furniture.
4. To remove dust from upholstery in home or auto.

3. Operation

1. Open the cover, according to the direction of the arrows, then insert battery.
2. On / Off: Push the on/off button with your right thumb and turn on the motor.
3. To Clean the Filter: Press the PUSH button to open the base cover according to the direction of the arrows. Take out the filter . Remove the dirt with tiny brush. Once the filter is removed of all debris, you may rinse it with water and replace back on unit.

4. Caution

1. DO NOT--dip this cleaner in water, it will damage the motor.
2. DO NOT--use any oil or solvents to clean it. Dry wipe.
3. DO NOT--try to remove dust with just any tool, use the brush.
4. DO NOT --open the base cover when switch in turned on.
5. Please change the battery, when units suction is not strong.

LIMITED ONE YEAR WARRANTY

Retain This Part For Future Use

This warranty is only valid in the USA

This warranty does not cover damage caused by accident, misuse, abuse, or failure to follow instructions contained in your owner's manual. No refunds. Exchanges only.

RETURN INSTRUCTIONS:

1. Please call Techko Maid's Customer Service Line prior to returning product to the store or seeking warranty replacement (888-883-2456)
2. **When returning a product to Techko Maid, please follow the instruction below.**
 - a. Call (888-883-2456) for a Return Authorization Number (RA #)
DO Not mail without receiving a RA#.
 - b. Pack the product in the original carton or equivalent
 - c. Enclose a copy of the original, dated proof of purchase
 - d. Enclose a note explaining the difficulty you are experiencing with the product. Please be sure to enclose your full name, address and telephone no. Print your RA# in the bottom left corner of your package.
 - e. Enclose a check or money order (no cash) payable to Techko Maid, Inc. In the amount of \$ 10.00 for shipping and handling on your replacement.
 - f. Mail the above to : Techko Maid, Inc. 11 Marconi Street Suite A, Irvine, Ca. 92618
 - g. Please allow 4-6 weeks for warranty service.