

SCREEN HEIGHT POSITION ILLUSTRATIONS ON A HINGED DOOR

Typical Installation:



Other Installation: A filler board (trim) may be needed if the screen is positioned differently or if the opening height is outside of the recommended size range.

Filler
Board

