

This quick reference guide to laundry accessories will help to make sure you have what you need for a successful installation in just 3 easy steps.

- Step 1** Find your model number in this guide. Model numbers that contain an underscore (_) are available in multiple colors. For example, WM6500H_A comes in both White (WM6500HWA) and in Black Steel (WM6500HBA). DLG3401W does not have the underscore as it only comes in White. Be sure to confirm availability and ordering of consistent model colors across washer, dryers, and pedestals if desired.
- Step 2** Read the information on required and optional accessories to determine your needs and prepare yourself by knowing the answers to the following questions.
- ☐ Gas or electric dryer?
 - ☐ Side-by-side or stacked installation?
 - ☐ If a side-by-side installation, do you want pedestals?
 - ☐ If purchasing a gas dryer, is your home natural gas (NG) or liquid propane (LP)?
- Step 3** Identify the items you need to purchase for your washer and dryer. Items with a check box need to be purchased separately.

Where to Buy?

Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.[†]

Optional Accessories

Purchase by clicking the LG parts & accessories button[†] call 1-800-243-0000.

LG Parts & Accessories

Contents

WashTower™ with Center Control™	2
Front Load Pairs	3
29" Wide Front Load Laundry Pairs	
27" Wide Front Load Laundry Pairs	
Top Load Pairs	4
Specialty Front Load Pairs	5
27" All-in-One Washer / Dryer Combos	
24" All-in-One Washer / Dryer Combos	
24" Wide Compact Front Load Laundry Pairs	



[†]www.lg.com/us/support/lg-direct-service/parts-and-accessories

What Accessories Do I Need to Purchase for My LG WashTower™?

Washer w/ Electric Dryer
Washer w/ Gas Dryer
Washer w/ Heat Pump Dryer

- ☐ Items in RED with a check box require you to make a purchase
- ☐ Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER	
WashTower™ with Center Control™	
SWWE50N3*, SWWE50W4*, WKEX300HBA*, WKEX200H_A(B,W,G)*, WKE100H_A(V,W)	
SWWG50N3*, SWWG50W4, WKGX301HBA*, WKGX201H_A(B,W,G)*, WKG101H_A(V,W)	
	WKHC252H_A(W,B), WKHC152HWA

STEP 2: READ THIS INFORMATION		STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER	
Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.† 	Water Supply Requirements Washers must be connected to a hot water supply with a temperature range between 120°F and 130°F. Required min. / max. water pressure is 20 –120 psi.	☐ Washer Water Supply Hoses (Hot & Cold)	
	Dryer Electrical & Venting Requirements (Note: Venting ductwork is not provided and should be purchased separately, if required. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)	☐ Dryer Water Supply Hose (Cold) (Only Required for Steam Dryers with * in Listing Above)	Not Applicable
	☐ Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)		
	☐ Gas Dryers Require a Flexible Stainless Steel Gas Connector Kit		Not Applicable
Optional Accessories Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000 	LP Conversion Kit If ordering a Gas Dryer and your home uses Liquid Propane (LP) instead of Natural Gas (NG), order an LP Conversion Kit. (Kit is not needed if you are ordering an LP Conversion Installation thorough your retailer. In this case, the installer will provide the necessary LP Conversion Kit.)	☐ All Dryers Require a Transition Duct Installation Kit. (All dryers are shipped for Rear Venting)	Not Required
	All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.)	☐ LP Conversion Kit – 383EEL3002D (Not needed if you are ordering an LP Conversion Installation. See details on the left.)	Not Applicable
	Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling.	☐ Side / Bottom Vent Kit – 3911EZ9131X (Only Required if You are not Venting from the Rear; Interchangeable with 383EEL9001B)	Not Applicable
		Drying Rack Included (SWWE50N3, SWWG50N3, SWWE50W4, SWWG50W4) ☐ Drying Rack – 3750EL1001A (for WKEX300HBA, WKGX301HBA, WKEX200H_A, WKGX201H_A, WKE100H_A, WKG101H_A, WKHC202HBA)	

○ W – Essence White ▲ N – Noble Steel ● B – Black Steel ● G – Nature Green ● V – Graphite Steel ○ W – White

*Steam dryer +An underscore in the model number “_” indicates the model is available in multiple colors. Confirm color availability for the pair you are purchasing and be sure to order the same color for the washer, dryer, and pedestals. **A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong dryer power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong dryer power cord. LG recommends a 4-wire connection and a 4-prong dryer power cord. †www.lg.com/us/support/lg-direct-service/parts-and-accessories



ACCESSORY GUIDE: FRONT LOAD LAUNDRY

What Accessories Do I Need to Purchase for My LG Front Load Laundry Pair?

☐ Items in RED with a check box require you to make a purchase

☐ Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER			
29" Wide Front Load Laundry Pairs		27" Wide Front Load Laundry	
Washers	WM8900HBA	WM6700HBA; WM6500H_A(B,W), WM5700HVA, WM5500H_A(V,W), WM4200H_A(W,B), WM4000H_A(B,W), WM3470C_(M,W), WM3400CW	WM5500H_A
Electric Dryers	DLEX8900B*	DLEX6700B*, DLEX6500_(B,W)*, DLEX5500_(V,W)*, DLEX4200_(W/B)*, DLEX4000_(B,W)*, DLE3470_(M,W), DLE3400W	DLHC5502_(V,B,W)
Gas Dryers	DLGX8901B*	DLGX6701B*, DLGX6501_(B,W)*, DLGX5501_(V,W)*, DLGX4201_(W/B)*, DLGX4001_(B,W)*, DLG3471_(M,W), DLG3401W	
			 HEAT PUMP DRYER (NO VENTING REQUIRED)

STEP 2: READ THIS INFORMATION

Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button. [†] LG Parts & Accessories	Water Supply Requirements Washers must be connected to a hot water supply with a temperature range between 120°F and 130°F. Required min. / max. water pressure is 20–120 psi.	
	Dryer Electrical & Venting Requirements A min. 30 Amp circuit is required. (Note: Venting ductwork is not provided and should be purchased separately. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)	  
	LP Conversion Kit If ordering a Gas Dryer and your home uses Liquid Propane (LP) instead of Natural Gas (NG), order an LP Conversion Kit. (Kit is not needed if you are ordering an LP Conversion Installation thorough your retailer. In this case, the installer will provide the necessary LP Conversion Kit.)	
		

STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

Optional Accessories Purchase by clicking the LG parts & accessories button [†] or call 1-800-243-0000 LG Parts & Accessories	When installing side-by-side, you can add 2 pedestals or 1 LG SideKick™ and 1 pedestal. (Be sure to order the correct color to match your pair.+) 	☐ Washer Water Supply Hoses (Hot & Cold)	
	When installing in a stacked configuration, you must order a Stacking Kit. 	☐ Steam Dryer Installation Kit (Only Required for Steam Dryers with * in Listing Above)	Not Applicable
	All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.) 	☐ Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)	
	Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling. 	☐ Gas Dryers Require a Flexible Stainless Steel Gas Connector Kit	Not Applicable
Optional Accessories Purchase by clicking the LG parts & accessories button [†] or call 1-800-243-0000 LG Parts & Accessories	When installing side-by-side, you can add 2 pedestals or 1 LG SideKick™ and 1 pedestal. (Be sure to order the correct color to match your pair.+) 	☐ All Dryers Require a Transition Duct Installation Kit	Not Required
	When installing in a stacked configuration, you must order a Stacking Kit. 	☐ LP Conversion Kit – 383EEL3002D (Not needed if you are ordering an LP Conversion Installation. See details on the left.)	Not Applicable
	All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.) 	☐ Pedestal – WDP5B ☐ LG SideKick™ Pedestal Washer – WD200CB (Includes all Hoses and Connectors)	☐ Pedestal (13 5/8" H) – WDP6_(V, B, W, M) ☐ ADA Pedestal (5 1/8" H) - WDPS2_(B, W) ☐ LG SideKick™ Pedestal Washer – WD300C_ (V, B, W) (Includes all Hoses and Connectors)
	Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling. 	☐ Stacking Kit – KSTK2	☐ Stacking Kit – KSTK4
Optional Accessories Purchase by clicking the LG parts & accessories button [†] or call 1-800-243-0000 LG Parts & Accessories	When installing side-by-side, you can add 2 pedestals or 1 LG SideKick™ and 1 pedestal. (Be sure to order the correct color to match your pair.+) 	☐ Side / Bottom Vent Kit – 383EEL9001L (Only Required if You are not Venting from the Rear)	☐ Side / Bottom Vent Kit – 3911EZ9131X (Only Required if You are not Venting from the Rear; Interchangeable with 383EEL9001B)
	When installing in a stacked configuration, you must order a Stacking Kit. 	☐ Drying Rack – MGR62082001	☐ Drying Rack – 3750EL1001A (for DLEX6700B, DLGX6701B, DLEX6500_, DLGX6501_, DLEX5500_, DLGX5501_, DLEX4200_, DLGX4201_, DLEX4000_, DLGX4001_) ☐ Drying Rack – 3750EL1001D (for DLE3470_, DLG3471_, DLE3400W, DLG3401W)
	All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.) 		
	Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling. 		

● B – Black Steel ● B – Matte Black ● M – Middle Black ● M – Monochrome Grey ● V – Graphite Steel □ W – Alpine White ○ W – White

*Steam dryer +An underscore in the model number “_” indicates the model is available in multiple colors. Confirm color availability for the pair you are purchasing and be sure to order the same color for the washer, dryer, and pedestals. **A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong dryer power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong dryer power cord. LG recommends a 4-wire connection and a 4-prong dryer power cord. [†]www.lg.com/us/support/lg-direct-service/parts-and-accessories



ACCESSORY GUIDE: TOP LOAD LAUNDRY

What Accessories Do I Need to Purchase for My LG Top Load Laundry Pair?

- ☐ Items in RED with a check box require you to make a purchase
- ☐ Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

What Accessories Do I Need to Purchase for My LG Top Load Laundry Pair?			STEP 1: FIND YOUR MODEL NUMBER		
Washers Electric Dryers Gas Dryers	WT8600CB	WT8400C_(B,W), WT8405C_(B,W), WT7150C_(M,W), WT7155CW, WT7000CW, WT7005CW, WT6100CW, WT6105C_(M,W)			
	DLEX8600BE*	DLE8400_E(B,W), DLE7150_(M,W), DLE7000W, DLE6100_(M,W)			
	DLGX8601BE*	DLG8401_E(B,W), DLG7151_(M,W), DLG7001W, DLG6101_(M,W)			
					
☐ Items in RED with a check box require you to make a purchase ☐ Items in BLACK with a check box are optional Items in BLACK without a box are included with purchase.			STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER		
Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.[†] LG Parts & Accessories	Water Supply Requirements Washers must be connected to a hot water supply with a temperature range between 120°F and 130°F. Required min. / max. water pressure is 20 – 120 psi.		☐ Washer Water Supply Hoses (Hot & Cold)		
	Dryer Electrical & Venting Requirements A min. 30 Amp circuit is required. (Note: Venting ductwork is not provided and should be purchased separately. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)		Steam Dryer Water Supply Hoses & Y-Connector Included	Not Applicable	
			☐ Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)		
			☐ Gas Dryers Require a Flexible Stainless Steel Gas Connector Kit		
			☐ All Dryers Require a Transition Duct Installation Kit		
LP Conversion Kit If ordering a Gas Dryer and your home uses Liquid Propane (LP) instead of Natural Gas (NG), order an LP Conversion Kit. (Kit is not needed if you are ordering an LP Conversion Installation thorough your retailer. In this case, the installer will provide the necessary LP Conversion Kit.)		☐ LP Conversion Kit – 383EEL3002D (Not needed if you are ordering an LP Conversion Installation. See details on the left.)			
Optional Accessories Purchase by clicking the LG parts & accessories button[†] or call 1-800-243-0000 LG Parts & Accessories	All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.)		☐ Side / Bottom Vent Kit – 3911EZ9131X (Only Required if You are not Venting from the Rear; Interchangeable with 383EEL9001B)		
	Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling.		☐ Drying Rack – 3750EL0001C		

● B – Black Steel ■ B – Matte Black ● M – Middle Black ● M – Monochrome Grey ● V – Graphite Steel □ W – Alpine White ○ W – White

*Steam dryer +An underscore in the model number “_” indicates the model is available in multiple colors. Confirm color availability for the pair you are purchasing and be sure to order the same color for the washer, dryer, and pedestals. **A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong dryer power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong dryer power cord. LG recommends a 4-wire connection and a 4-prong dryer power cord. [†]www.lg.com/us/support/lg-direct-service/parts-and-accessories

What Accessories Do I Need to Purchase for My LG Specialty Front Load Laundry Pair?

Washer / Dryer Combos

Washers
Electric Dryers
Gas Dryers

- ☐ Items in RED with a check box require you to make a purchase
☐ Items in BLACK with a check box are optional
 Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER

27" All-in-One Washer / Dryer Combos	24" All-in-One Washer / Dryer Combos	24" Wide Compact Front Load Laundry Pairs
WM6998H_A(B,V)	WM3555H_A(V,W)	—
—	—	WM1455HWA
—	—	DLHC1455W
—	—	—
 HEAT PUMP DRYER (NO VENTING REQUIRED)		 HEAT PUMP DRYER (NO VENTING REQUIRED)

STEP 2: READ THIS INFORMATION

Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button. [†] LG Parts & Accessories	Water Supply Requirements Washers must be connected to a hot water supply with a temperature range between 120°F and 130°F. Required min. / max. water pressure is 20 –120 psi.	 
	Dryer Electrical & Venting Requirements (Note: Venting ductwork is not provided and should be purchased separately, if required. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)	  
	LP Conversion Kit If ordering a Gas Dryer and your home uses Liquid Propane (LP) instead of Natural Gas (NG), order an LP Conversion Kit. (Kit is not needed if you are ordering an LP Conversion Installation thorough your retailer. In this case, the installer will provide the necessary LP Conversion Kit.)	

STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

☐ Washer Water Supply Hoses (Hot & Cold)		Hoses Included. No Additional Purchase Required.
Steam Dryer Water Supply Hoses & Y-Connector — Not Applicable		
Electric Dryer Power Cord — No Additional Purchase Required	☐ Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)	
Gas Connector Kit — Not Applicable		
Ventless Condensing Dryer Does Not Require Venting	Heat Pump Dryer Does Not Require Venting	
Not Applicable		
☐ Pedestal – WDP6B ☐ ADA Pedestal (5 1/8" H) – WDPS2B ☐ LG SideKick™ – WD300CB (Includes all hoses and connectors)	Not Applicable	
Stacking Kit - KSTK4	Not Stackable	Stacking Kit Included with Dryer
Ventless Condensing Dryer Does Not Require Venting	Heat Pump Dryer Does Not Require Venting	
Not Applicable		

● V — Graphite Steel ● B — Black Steel ○ W — White

*Steam dryer +An underscore in the model number “_” indicates the model is available in multiple colors. Confirm color availability for the pair you are purchasing and be sure to order the same color for the washer, dryer, and pedestals. **A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong dryer power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong dryer power cord. LG recommends a 4-wire connection and a 4-prong dryer power cord. [†]www.lg.com/us/support/lg-direct-service/parts-and-accessories