


Item #1004403555 Model #SK19051Dr1-SB

USE AND CARE GUIDE

ROYCE FILE CABINET



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service. 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-998-7021

HOMEDEPOT.COM/HOMEDECORATORS

THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this Royce file cabinet. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

Table of Contents

Table of Contents	
Safety Information	
Warranty 3 Year Warranty	
What is Covered	
What is Not Covered	2
Pre-assembly	
Planning Assembly	
Tools Required	3

Safety Information

- □ Keep small parts away from children during assembly.
- **Read and follow instructions carefully.**

- □ Read these instructions carefully and keep in a safe place.
- TO GUARANTEE THE SAFE USE OF THIS PRODUCT, FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL.
- □ Adult assembly required.
- □ Small parts may present choking hazard prior to assembly.
- Do not place heavy objects on the glass top.
- □ Some assembly may involve attaching glass or mirrors.
- Be very careful handling the glass or mirrors, as severe injury may result if the glass or mirror breaks.
- □ Never handle large pieces of glass or mirrors by yourself.

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

We guarantee this product to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

This warranty does not cover commercial use, acts of nature, and abusive use.

Hardware Included	3
Pre-assembly (continued)	4
Package Contents	
Assembly	5


- Do not use power tools to assemble your furniture. Power tools may strip or damage parts/product.
- Do not overtighten connectors (screws, bolts, etc.).
 Overtightening can lead to product damage.
- Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact THE HOME DEPOT to obtain any missing parts.
- DO NOT USE SUBSTITUTE PARTS.
- □ This product should only be used on a flat, level surface.

Pre-assembly


PLANNING ASSEMBLY

Keep children and pets away from build area. Make sure your area is large enough to unpack, sort and assemble the unit.

TOOLS REQUIRED




HARDWARE INCLUDED



Part	Description	Quantity
AA	Wood dowel	16
BB	Cam lock bolt	18
CC	Cam lock	18
DD	1 in.Flat head screw	16
EE	Bolt	2
FF	Knob	2
GG	Anti-tipping hardware package	1

Pre-assembly (continued)

PACKAGE CONTENTS




Part	Description	Quantity
Α	Top panel	1
В	Left side panel	1
C	Right side panel	1
D	Bottom panel	1
E	Crossbar	1
F	Back panel	1
G	Drawer front panel	2
Н	Top drawer left side panel	1
I	Top drawer right side panel	1
J	Drawer back panel	2
K	Drawer bottom panel	2
L	Metal bar	4
М	Bottom drawer left side panel	1
N	Bottom drawer right side panel	1

Assembly


Attaching the back panel to the left side panel

a) Install dowel (AA) and bolt (BB) into panel (B).




□ b) Insert lock (CC) into panel (F).

□ c) Join panel (F) to the panel (B) with dowel (AA).




d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.




$2 \, ^{\rm Attaching \, the \, crossbar \, and}_{\rm right \, side \, panel}$

a) Install dowel (AA) and bolt (BB) into panel (C).




□ b) Insert lock (CC) into panel (F) and bar (E).

□ c) Join bar (E) and panel (F) to the panels (B) and (C) with dowel (AA).




d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.




${f 3}$ Attaching the bottom panel

a) Install dowel (AA) and bolt (BB) into panel (D).




□ b) Insert lock (CC) into panels (B),(C) and (F).

 $\hfill\square$ c) Join panel (D) to the assembled body with dowel (AA).




 $\hfill\square$ d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.




4 Attaching the top panel

a) Install bolt (BB) into panel (A).



 $\hfill\square$ b) Insert lock (CC) into panels (B),(C) and (F).




(**CC**) x 6

Ĥ


(AA) x 4

(**BB**) x 6

 $\hfill\square$ c) Join panel (A) to the assembled body with dowel (AA).




d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.



Ć


${f 5}$ Assembling the drawer

 \square a) Tighten panels (I) and (H) to panel (G) with screw (DD).




□ b) Slide panel (K) into the grooves on panels (I) and (H).

c) Tighten panel (J) to the assembled body with screw (DD).




 $\hfill\square$ d) Tighten knob (FF) to panel (G) with bolt (EE).

Insert metal bar (L) into panels (G) and (J).




$\mathbf{6}$ Assembling the drawer

□ a) Tighten panels (M) and (N) to panel (G) with screw (DD).




□ b) Slide panel (K) into the grooves on panels (M) and (N).

c) Tighten panel (J) to the assembled body with screw (DD).




 $\hfill\square$ d) Tighten knob (FF) to panel (G) with bolt (EE).

Insert metal bar (L) into panels (G) and (J).




$\mathbf{7}$ Inserting the drawer


□ Insert the drawer into the assembled body as shown.





${f 8}$ Finalizing the assembly

□ Install the anti-tipping hardware as shown.











Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service. 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-998-7021

HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.