



EXPLODED VIEW



PARTS LIST

REF	Part #	Description	QTY	Note
7	84002061	REAR COVER ASSEMBLY	1	
8	-----	COVER, Top, Battery	1	Order Wholegood
9	84002076	BATTERY HOUSING & PCB ASSEMBLY	1	
10	-----	MOTOR, Electric	1	Order Wholegood
11	-----	COVER, Side, Battery	1	Order Wholegood
13	770194	KIT, Side Discharge	1	
14	770193	SIDE COVER Assembly	1	
18	84002065	PLUG, Mulching	1	
20	-----	COVER, Top	1	Order Wholegood
21	-----	COVER, Bottom	1	Order Wholegood
22	84002068	KIT, Blade	1	
23	-----	BAFFLE, Rear	1	Order Wholegood
24	84002066	KIT, Rear Deflector	1	
42	1760266	BATTERY, 82V 2.0	1	Optional
43	1760265	BATTERY, 82V 4.0	1	Optional
44	1760967	BATTERY, 82V 5.0	1	Optional
45	1760263	CHARGER, Rapid 82V	1	Optional


EXPLODED VIEW



PARTS LIST

REF	Part #	Description	QTY	Note
1	84002042	PANEL ASSEMBLY	1	
2	84002043	UPPER HANDLE ASSEMBLY	1	
3	84001954	KIT, Locator, Handles	1	
4	84001931	HANDLE, Lower	2	
5	84001929	KIT, Handle, Release	1	
6	84001930	KIT, Hardware, Handle	1	
12	84001946	SWITCH, Vertical Storage	1	
15	770180	HANDLE, Height Adjust	1	
16	-----	HEIGHT ADJUST, Right	1	Order Wholegood
17	-----	HEIGHT ADJUST, Left	1	Order Wholegood
30	770182	GRASS BAG ASSEMBLY	1	
33	84002074	KIT, Drive Cable	1	
34	84002070	KIT, Control Knob	1	
35	84002075	KIT, Battery Release	1	
36	84001635	KIT, Slides	1	
38	84002071	KIT, Safety Key	1	
39	84002072	SWITCH, Operator Presence	1	
40	84002073	SWITCH, Speed Control	1	
41	84002064	KEY, Safety	1	

EXPLODED VIEW



PARTS LIST

REF	Part #	Description	QTY	Note
19	-----	MOWER DECK	1	Order Wholegood
25	84002067	KIT, Gearbox	1	
26	-----	AXLE, Rear Wheel	1	Order Wholegood
27	770186	KIT, Front Axle	1	
28	84001935	SPRING, Height Adjust	1	
29	-----	BAR, Height Adjust	1	Order Wholegood
31	84002069	KIT, Rear Wheel	2	
32	770188	KIT, Front Wheel	2	

Not for
Reproduction