

It is the responsibility of the individual consumer purchaser to assure that all parts included in the factory-sealed carton are properly installed, all functional parts are initially adjusted properly, and subsequent normal maintenance services and adjustments necessary to keep the bike in good operating condition are the properly made. This warranty does not apply to damage due to improper installation of parts or failure to properly maintain or adjust the bike.

NOTICE: Specifications subject to change without notice.

PACIFIC CYCLE (UK) LTD

Vantage Way
The Fulcrum
Poole, Dorset
BH12 4NU


CUSTOMER SERVICE / WARRANTY

Tel: 01202 732288
Email: customer-service@pacific-cycle.co.uk
Monday-Friday 9:00am-5:00pm



SCHWINN
EST. 1895

Roadster Trike



OWNER'S MANUAL

This manual contains important safety, performance and maintenance information. Read the manual before taking your first ride on your new trike and keep the manual handy for future reference.

Rules for Children

To avoid accidents, teach children good riding skills with an emphasis on safety from an early age.

1. Rider should always wear a properly fitted helmet.
2. Continuous adult supervision required.
3. Allow only one rider.
4. Excessive weight may make the trike unstable and may be hazardous.
5. Do not play in driveways or on the road.
6. Do not ride on busy streets.
7. Do not ride at night.
8. Never take your hands off the handlebars, or your feet off the pedals when riding downhill.
9. Never stand on rear deck while cycling. This may cause instability and result in a fall.



WARNING! A protective helmet should be worn when cycling!

Children should be made aware of all possible riding hazards and correct riding behaviour before they take to the streets.

A SPECIAL NOTE FOR PARENTS

This trike is intended for use by small children. As a parent or guardian, you bear the responsibility of ensuring the safety of your child. To make sure this trike is used safely, a responsible adult must supervise any child playing with it. This includes allowing it to be used only where and when it is safe for a small child to do so and making certain that it is in good repair and secure operating condition.

This trike should be fully assembled by an adult due to potential small parts.

Not suitable for children under 36 months.

This product is not intended for road use.

Schwinn Roadster Trike Assembly Instructions

Tools required (not included):

13mm (1/2") wrench, or 10mm crescent (adjustable) wrench, screwdriver.

Before starting assembly, unpack and inspect all parts listed on the next page. If any parts are missing or damaged. DO NOT RETURN TRIKE TO DEALER.

To obtain spares or replacement parts, please contact:

Customer Services

tel. 10202 732288

email: customer-service@pacific-cycle.co.uk

Monday - Friday 9:00am - 5:00pm

Schwinn Roadster Trike Parts Diagram



1. Rear deck assembly
2. Handlebars
3. Saddle
4. Saddle securing bolt and nut
5. Frame
6. Front wheel, forks and pedals
7. Stern clamp

Step 1

Remove the washer, nut, and two flanking screws from the rear deck. Attach the rear deck to the main frame by aligning the rear axle against the 'C' shaped support at the end of the main frame, then rotate the rear deck so that the attachment bolt protrudes through the frame. Insert the two flanking screws, and secure the frame with the washer and locknut.



Step 2

Position saddle on frame with carriage bolt protruding through centre hole in frame. Tighten knob onto carriage bolt to lock saddle in position. Saddle adjustment can be achieved by removing the saddle-adjustment knob are re-tightening the knob and saddle in desired hole.



Step 3

Insert forks through head tube of frame. Be sure that the fork is completely inserted through frame to allow approximately 22mm (7/8") of fork steer tube to show through top of head tube, as pictured below.




Step 3 continued

Push stem clamp onto fork steer tube. Ensure there is no space between the head tube and stem clamp. Insert handlebar into fork steer. Be sure to insert far enough to cover the 'minimum insertion' mark on the handlebar. Align handlebar and front wheel and tighten stem clamp with 13mm (1/2") wrench.



Note: Ensure minimum insertion mark (pictured) is not visible.

Minimum insertion mark



Step 4

Ensure that each wheel is able to spin without resistance. If any wheel does not turn freely, check that the mudguard is not rubbing on the tyre. If this is the case, it is necessary to flex the mudguard until it is clear of the tyre. (see photograph below).

Additionally, check that the handlebars do not move independently of the front wheel. Tighten the stem clamp if necessary.



LIMITED WARRANTY AND POLICY ON REPLACEMENT PROCEDURES AND RESPONSIBILITIES

Your purchase included the following warranty which is in lieu of all other express warranties. This warranty is extended only to the initial consumer purchaser. No warranty registration is required.

The entire trike frame is guaranteed against faulty materials and workmanship for as long as the initial consumer purchaser has the bike, subject to the condition of the warranty listed below. If frame failure should occur due to faulty materials of workmanship during the guarantee period, the frame will be replaced. For frame replacement under this Pacific Cycle (JK) Ltd Warranty, contact us, stating the nature of the failure, model number, date received and the name of the store from which the trike was received, at the address given on this page. Trike frames must be returned for inspection at customer's expense.

All other parts of the unit except Normal Wear Parts are warranted against defective materials and workmanship for a period of 1 year from the date of purchase by the initial consumer purchaser, subject to the Terms and Conditions of the warranty listed below. If failure of any part should occur during the warranty period, the part will be replaced for you if the failure was due to faulty materials of workmanship. All warranty claims must be submitted to the address below and must be shipped prepaid and accompanied by proof of purchase.

Any other warranty claims not included in this statement are void. This especially included installation, assembly, and disassembly costs. This warranty does not cover paint damage, rust, or any modifications made to the bike. Normal Wear Parts are defined as grips, tyres, tubes, and cables. These parts are warranted to be free from defects in material and workmanship as delivered with the product. Any claim for repair or replacement of Normal Wear Parts (grips, tubes, tyres, cables, brake shoes, and saddle covering) and missing parts must be made within thirty (30) days of the date of purchase. The warranty does not cover normal wear and tear, improper assembly or maintenance, or installation of parts or accessories not originally intended or compatible with the tricycle as sold. The warranty does not apply to damage or failure due to accident, abuse, misuse, neglect, or theft. Claims involving these issues will not be honoured.

Your trike has been designed for general transportation and recreational use, but has not been designed to withstand abuse associated with stunting and jumping. This warranty ceases when you rent, sell, or give away the trike, ride with more than one person, or use the trike for stunting or jumping. This warranty does not cover ordinary wear and tear or anything you break accidentally or deliberately.