



## MEASUREMENT GUIDE

Thank you for selecting BELLDINNI™ interior doors.  
Please, read this guide to choose a proper size of the door.  
The sizes indicated on the website are matching with the rough opening dimensions.  
We will be glad to answer your questions in the Q&A section of the product page.

Slab Dimensions	Unit Dimensions (Prehung door)	Rough Opening Dimensions
17-3/4" x 79-3/8" x 1-3/4"	25-7/16" x 81-1/4" x 4-9/16"	20" x 82"
23-7/8" x 79-3/8" x 1-3/4"	25-7/16" x 81-1/4" x 4-9/16"	26" x 82"
27-3/4" x 79-3/8" x 1-3/4"	29-5/16" x 81-1/4" x 4-9/16"	30" x 82"
29-3/4" x 79-3/8" x 1-3/4"	31-5/16" x 81-1/4" x 4-9/16"	32" x 82"
31-3/4" x 79-3/8" x 1-3/4"	33-5/16" x 81-1/4" x 4-9/16"	34" x 82"
35-7/8" x 79-3/8" x 1-3/4"	37-7/16" x 81-1/4" x 4-9/16"	38" x 82"