

Model A1215-005

12 VOLT DC PORTABLE FAST FLOW INFLATOR



Press "ⓘ" to select the unit of measurement between psi, bar, kpa and kg/cm².

③



Connecting the air hose to the car tire.

②



Press the button "ⓘ" to switch this unit on or off.

⑥



Connect the 12V DC cord to your vehicle's 12V DC socket.

①



Press the "ⓘ" button to switch the 5 models.



④



Press "+" or "-" to increase or decrease the target pressure figure.

⑤



Press the button "ⓘ" to cycle through a continuous white light, a slow-flashing white light, a fast-flashing white light, or to turn off the light.

⑦

