

EXPLODED VIEW AND PARTS LIST

No.	Part No.	Description	Qty.
1	DF475-001	Rotor Stator Assembly	1
1.1	DF475-001.1	Carbon Brush Assembly	1
1.2	DF475-001.2	Grounding Post Assembly	1
1.3	DF475-001.3	Rotor	1
1.4	DF475-001.4	Stator	1
2	DF475-002	Motor Stand	1
3	DF475-003	Switch Dial Assembly	1
4	DF475-004	Hexagon Pattern Pan Head Screws M6X12	1
5	DF475-005	Nut M8	6
6	DF475-006	Wire Harness Clip	1
7	DF475-007	Frame	1
8	DF475-008	Isolator A	2
9	DF475-009	Isolator B	2
10	DF475-010	Fuel Filter	1
11	DF475-011	Fuel Tank Assembly	1
12	DF475-012	Fuel Cock	1
13	DF475-013	Regulator Assembly	1
14	DF475-014	Regulator	1
15	DF475-015	Bolt M6X55	1
16	DF475-016	Flat Washer	2
17	DF475-017	Bolt M8X1X220	1
18	DF475-018	Rotor Bolt Gasket Ø8.5X24X3	1
19	DF475-019	Handle Assembly	1
20	DF475-020	Bolt M6X175	4
21	DF475-021	Bolt M6X12	5
22	DF475-022	Nut M5	3
23	DF475-023	Air Cleaner Bracket	1
24	DF475-024	Exhaust Gasket	1
25	DF475-025	Cotter Pin	2
26	DF475-026	Muffler Comp	1
27	DF475-027	Spring Washer Ø8	2
28	DF475-028	Bolt M6X40	2
29	DF475-029	Panel Assembly	1
29.1	DF475-029.1	Shut Down Switch	1
29.2	DF475-029.2	DC Receptacle 12V	1
29.3	DF475-029.3	Thermal Protector 8A/Csa	1
29.4	DF475-029.4	Nema5-20R 120V 20A Du- plex	1
29.5	DF475-029.5	Thermal Protector 20A/Csa	1
29.6	DF475-029.6	Change-Over Switch	1
29.7	DF475-029.7	Thermal Protector 16A/Csa	2
29.8	DF475-029.8	Nema L14-30R 125V/250V 30A Twistlock	1
30	DF475-030	Handle Clip	1
31	DF475-031	Bolt M8X35	2
32	DF475-032	Bolt M6X40	4
33	DF475-033	Automatic Voltage Regulator	1

No.	Part No.	Description	Qty.
34	DF475-034	Bolt M5X16	1
35	DF475-035	Bolt M5X12	7
36	DF475-036	Fuel Tank Washer	4
37	DF475-037	Bolt M6X25	4
38	DF475-038	Generator End Cover	1
39	DF475-039	Positive Lead	1
40	DF475-040	Negative Lead	1
41	DF475-041	Battery	1
42	DF475-042	Wheel	2
43	DF475-043	Frame Support	2
44	DF475-044	Vibration Isolation Pad	2
45	DF475-045	Nut M6	6
46	DF475-046	Bolt M8X16	2
47	DF475-047	Clip Ø12	3
48	DF475-048	Wheel Axle	2
49	DF475-049	Handle Connector	1
50	DF475-050	Muffler Bracket	1
51	DF475-051	Battery Holder	1
52	DF475-052	Battery Pull Rod	2
53	DF475-053	Low Pressure Pipe 500mm	1
54	DF475-054	Low Pressure Pipe 250mm	1
55	DF475-055	Fuel Line (Ø8.5X4.5)/ Ø10X6)X250	1
56	DF475-056	Fuel Line Ø10X6X120	1
57	DF475-057	Connecting Pipe (Gas Tank)	1
58	DF475-058	Manual Choke Assembly	1
59	DF475-059	Handle Bolt	1
60	DF475-060	Fuel Line Clip Ø7.5	1
61	DF475-061	Fuel Line Clip, Ø9.5	5
62	DF475-062	Frame Wire	1
63	DF475-063	Fuel Line Clip Ø10	2
64	DF475-064	Nut M8	7
65	DF475-065	Tooth Type Gasket Ø6	1
66	DF475-066	Tooth Type Gasket Ø5	1
67	DF475-067	Handle Rubber	1
68	DF475-068	Bolt M6X30	1
69	DF475-069	Grounding Wire	1
70	DF475-070	Fuel Selector Switch	1
71	DF475-071	Bolt M6X16	4
72	DF475-072	Paper Washer	4
73	DF475-073	Fuel Tank Cap Assembly	1
74	DF475-074	LPG Regulator Cover	1
75	DF475-075	Carbon Tank Assembly	1
76	DF475-076	Connecting Pipe	1
77	DF475-077	Dustproof Sheet	1
78	DF475-078	Fuel Gauge	1
79	DF475-079	Fuel Tank Filter	1
80	DF475-080	Engine Complete	1
81	DF475-081	LPG Hose Assembly (not pictured)	1

EXPLODED VIEW AND PARTS LIST

No.	Part No.	Description	Qty.	No.	Part No.	Description	Qty.
1	DF475-101	Crankcase	1	40	DF475-140	Camshaft Assembly	1
2	DF475-102	Ball Bearing	2	41	DF475-141	Dowel pin	2
3	DF475-103	Oil Seal	2	42	DF475-142	Bolt M8X30	6
4	DF475-104	Governor Assembly	1	43	DF475-143	Cylinder Head Gasket	1
5	DF475-105	Governor Arm Shaft	1	44	DF475-144	Bolt M8X60	4
6	DF475-106	Governor Arm Shaft Washer	1	45	DF475-145	Spark Plug	1
7	DF475-107	Lock Pin	1	46	DF475-146	Push Rod	2
8	DF475-108	Drain Plug Bolt	2	47	DF475-147	Shroud	1
9	DF475-109	Drain Plug Washer	2	48	DF475-148	Bolt M6x12	12
10	DF475-110	Oil Level Switch Assembly	1	49	DF475-149	Headcover Gasket	1
11	DF475-111	Bolt M6X16	2	50	DF475-150	Cylinder Head Cover	1
12	DF475-112	Cascover Dowel Pin Ø8X14	2	51	DF475-151	Wind Shield Assembly	1
13	DF475-113	Piston	1	52	DF475-152	Bolt M6x28	1
14	DF475-114	Piston Scraper Ring Set	1	53	DF475-153	Recoil Starter Fan	1
15	DF475-115	Connecting Rod Assembly	1	54	DF475-154	Starter Pulley	1
16	DF475-116	Piston Pin	1	55	DF475-155	Nut M14	1
17	DF475-117	Piston Clip	2	56	DF475-156	Ignition Coil Assembly	1
18	DF475-118	Crankcase Cover Assembly	1	57	DF475-157	Bolt M6X25	2
19	DF475-119	Cylinder Head	1	58	DF475-158	Intake Gasket	1
20	DF475-120	In-Valve	1	59	DF475-159	Carburetor Insulator	1
21	DF475-121	Valve Exhaust	1	60	DF475-160	Carburetor Gasket	1
22	DF475-122	Intake Valve Returner	1	61	DF475-161	Carburetor Spacer	1
23	DF475-123	Valve Spring	2	62	DF475-162	Governor Rod	1
24	DF475-124	In-Valve Spring Seat	1	63	DF475-163	Throttle Return Spring	1
25	DF475-125	Ex-Valve Spring Seat	1	64	DF475-164	Recoil Starter Assembly	1
26	DF475-126	Push Rod Guide Plate	1	64.1	DF475-164.1	Recoil Starter	1
27	DF475-127	Rocker Assembly	2	65	DF475-165	Upper Shroud Assembly	1
28	DF475-128	Rotator	1	66	DF475-166	Air Cleaner Assembly	1
29	DF475-129	Stud Bolt (Carburetor)	2	66.1	DF475-166.1	Air Filter Element	1
30	DF475-130	Stud Bolt	2	67	DF475-167	Breather Tube	1
31	DF475-131	Carburetor Assembly	1	68	DF475-168	Fuel Rubber	1
32	DF475-132	Fuel Line	1	69	DF475-169	Governor Spring	1
33	DF475-133	Fuel Line Clip Ø7.5	1	70	DF475-170	Clip	1
34	DF475-134	Governor Arm	1	71	DF475-171	Dipstick	1
35	DF475-135	Governor Arm Bolt	1	72	DF475-172	Bolt M6X30	2
36	DF475-136	Nut M6	3	73	DF475-173	Flywheel Assembly	1
37	DF475-137	Crankshaft Assembly	1	74	DF475-174	Starting Motor Assembly	1
38	DF475-138	Valve Lifter	2	75	DF475-175	Adjuster Rocker Arm	2
39	DF475-139	Cascover Gasket	1	76	DF475-176	Dustproof Sheet	1
				77	DF475-177	Cascover Dowel Pin Ø 8x12	2