


BYBLIGHT

BYBLIGHT
3 Arm Arc Floor Lamp
Lamp With Three Adjustable Arms



Features:

1. Three Adjustable Arms
2. Four Setting Switch
3. Included 3 LED Blubs

Package Included:

- | | |
|----------------------------|----------------------|
| (A) Top ring(3) | (L) Curved tube L(1) |
| (B) Bottom ring(3) | (M) Curved tube M(1) |
| (C) Linen lampshade(3) | (N) Rotary switch(1) |
| (D) Plastic cap(3) | (O) Pole O(1) |
| (E) Lamp holder(3) | (P) Pole P(1) |
| (F) Fixing ring(3) | (Q) Marble base(1) |
| (G) Bulb(3) | (R) Washer(1) |
| (H) Curved tube H(1) | (S) Nut(1) |
| (I) Screw(8, two for free) | (T) Wrench(1) |
| (J) Screwdriver(1) | |
| (K) Curved tube K(3) | |


Important Safety Instructions

- This portable luminaire has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.
- Do not attempt to defeat this safety feature.
- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
- This fixture has been rated for up to one (1) 60-watt maximum incandescent light bulb (not included) or one 6-Watt LED bulb (Included). To avoid the risk of fire, do not exceed the recommended wattage.
- This lamp is meant for indoor use.
- Save these instructions.


WARNING

- To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the light fixture and allow it to cool prior to replacing the light bulb.
- Keep flammable materials away from lit bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.

Installation




1. Connect the pole (O) and pole (P) along the wire extending from the bottom of pole (P), and pull the cord gently as you build.
2. Put the base on the ground and tighten the pole and base(Q).
3. Screw the washer(R) and nut(S) one by one into the bottom of the base with wrench(T).



4. Insert the curved tubes(K) into the pole's holes one by one and pull the cord gently.
5. Connect the curved tubes(HLM) and tubes(K) one by one, then pull the cord again.
6. Assemble the screws(I) into holes with screwdriver(J).
7. Screw the plastic caps(D) back to steady the cord.

Installation



8. Put the bottom ring on the table and fasten the 3/4 linen lampshade around the bottom ring.
9. Fasten the top ring to the upper lampshade and the rest 1/4 lampshade to the bottom ring.
10. Then fasten where the lampshade is joined end to end.
11. Fit the lampshades under the lamp holders(E).
12. Screw the rings(F) back to steady the lampshdes.
13. Install the bulbs(G).

How to use?

1. Four setting rotary switch on the main pole:1 light on,2 lights on,3 lights on,off.
2. Each adjustable arm can be moved side to side that you can position the lamp where you want.

Maintenance:

- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC COMPLIANCE:

This Class B digital apparatus complies with CAN ICES - 3(B)/NMB - 3(B)

1 YEAR WARRANTY

Byblight warrants this product to be free of defects in parts, materials and Workmanship for a period of one year, from date of purchase should any repairs Or servicing under this warranty be required, contact Customer Service by email for instructions on how to pack and ship the product to Byblight.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



Email: support@byblight.com