

## STEP 4

Attach Panel (A) to assembled unit and tighten Mini Fix Cam (3), as shown.



## Recommended Maximum Weight




## WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.


>Put heavier items on lower shelves.






No	Hardware List		Qty	No	
1	Dowel		4pcs	А	Top Par
2	Screw		8pcs	В	Left Side
3	Mini Fix Cam		4pcs	С	Right Si
4	Mini Fix Bolt		4pcs	D	Center I
5	Nail Leg (	))	4pcs	·1	

No	Parts List	Qty	
А	Top Panel	$\Diamond$	1pc
В	Left Side Panel	$\checkmark$	1pc
С	Right Side Panel	$\checkmark$	1pc
D	Center Bar		2pcs



## USEFUL HINTS BEFORE YOU START:

- 1. Read each step carefully before starting.
- 2. It is important that each step is performed in correct order to avoid difficulties.
- 3. Identify, sort and count the parts before assembly.
- 4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
- 5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
- 6. Using uncompatible hardware might cause damage to product.



3.2 Attach Panel (B) to the assembled unit with Screw (2), as shown.

