


SKU# 100 748 9799
Model# FRN-801820-B

HAMPTON BAY®

USE AND CARE GUIDE

WOODFORD BISTRO SET



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this bistro set. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Safety Information	2
Warranty	2
Pre-assembly	3-4

Hardware Included	3
Package Contents	4
Table Assembly	5
Chair Assembly	6-8
Care and Cleaning	9

Important Safety Information

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

SAVE THESE INSTRUCTIONS.

Due to the expansion and contraction of the wood caused by weather, we recommend re-tightening all of the hardware two weeks after assembly. Periodic checking of all connections and hardware is also advised.



DANGER: Keep children out of the assembly area during assembly.



CAUTION: DO NOT use pressure cleaning machines when cleaning your furniture or you will damage the structure of the wood.



CAUTION: DO NOT place hot objects directly on the wood surface to prevent damage to the wood.



CAUTION: DO NOT use sharp equipment such as a knife and scissors when removing the protective material as it may damage product.



WARNING: Do not stand on this chair.

Warranty

TWO YEAR LIMITED WARRANTY

WHAT IS COVERED

The frame is warranted to be free of manufacturing defects for two years from the purchase date. If the frame of your furniture fails (ie. broken frame or weld) within 2 years of ownership, Hampton Bay will repair, provide replacement parts, or replace the product at our option. Frame finishes are warranted against blistering, cracking, or peeling for 2 years from purchase date. This is a residential use warranty only. Warranty is void when product is used for commercial settings. This warranty is a limited warranty and applies to the original purchase only. Proof of purchase is required.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HAMPTONBAY.com.


Pre-assembly

PLANNING ASSEMBLY

Before beginning the assembly of this product, make sure all parts are present. Compare parts with Package Contents and Hardware Included lists. If any part is missing or damaged, do not attempt to assemble the product, and return it to the place of purchase. Assembly requires two people.

HARDWARE INCLUDED

 **NOTE:** Hardware not shown to actual size.




Part	Description	Quantity
AA	Nut	8
BB	Washer	8
CC	Wrench	1
DD	Bolt M6x50	2
EE	Allen Key	2
FF	Screw M6x40	16
GG	Bolt M6x80	8
JJ	Cap Nut M6	8
KK	Cap	16

Pre-assembly (continued)

PACKAGE CONTENTS


A




B




E




F




I




J




K



L



M




Part	Description	Quantity
A	Table Top	1
B	Table Leg	4
E	Right Arm	2
F	Left Arm	2
I	Back Cushion	2
J	Seat Cushion	2
K	Backrest Frame	2
L	Seat Frame	2
M	Connect Bar	2

Table Assembly


1 Attaching the Legs to the Table To the Table Top

- Place all parts on a flat, clean surface.
- Attach the Table Legs (B) to the Table Top (A) by using the Nut (AA), Washers (BB), then use the Wrench (CC) to secure.



2 Completing the Assembly


- Turn the table right side up and place on a flat surface. Adjust the plastic leveling feet if the four legs are not level.
- The table is ready to use now.



Chair Assembly



1 Attaching Left Arm to the Chair Backrest Frame

- Place all parts on a flat, clean surface.
- Attach the Left Arm (F) and Connect Bar (M) to the Backrest Frame (K) by using the Bolt M6x50 (DD), Cap Nut M6 (JJ), Bolt M6x80 (GG), Screw M6x40 (FF) and Allen Key (EE), then use the Allen Key to secure.
- Do not fully tighten all the bolts in this step.



2 Attaching Right Arm to the Chair Backrest Frame


- Attach the Right arm (E) and Seat Frame (L) to the Backrest Frame (K), by using the Bolt M6x50 (DD), Cap Nut M6 (JJ), Bolt M6x80 (GG), and Allen Key (EE).
- Do not fully tighten all the bolts in this step.



Chair Assembly (continued)


3 Tightening Backrest Frame

- Tighten Backrest Frame (K) with Screw M6x40 (FF) and Allen Key (EE).



4 Tightening Seat Frame


- Tighten Seat Frame (L) with Screw M6x40 (FF) and Allen Key (EE). Then fully tighten all the bolts on this chair.
- Use Cap (KK) to cover all exposed bolts.



Chair Assembly (continued)

5 Completing the Assembly

- Place the chair on a flat surface and put Seat Cushion (J) and Back Cushion (I) on the chair.
- Now the chair is ready to use.



Care and Cleaning

- Always make certain to cover your outdoor wood furniture with waterproof covers when you are not using it. Using covers will protect your furniture from all weather elements and prolong the life of the wood furniture. Do not use plastic covers to protect your furniture as this may cause mold to grow on your furniture.
- This furniture has been treated with a PU (polyurethane) protectant during production; however, all timber surfaces will change color and may become rough over time. Since the wood used is a natural resource, you may find color variations with each piece. New furniture will initially vary in color from items that have been previously purchased.
- Please re-oil the wood every 12 weeks or whenever the wood appears to be dry to retain a good level of protection. We recommend using a boiled linseed oil. Please follow the product instructions carefully when using this product on your furniture set. Regular oiling will minimize cracking but won't eliminate it. Cracking of the timber does not affect the durability of the product.
- When cleaning the cushions, use a mild soap and water mixture (DO NOT USE BLEACH) and gently rub the surface of the fabric and rinse with water. Allow time for cushions to dry before use. Always cover your cushions with waterproof covers when you are not using it to prolong the life of the cushions.
- When moving the furniture, DO NOT drag pieces as this may cause damage to the wood joints and cause cracking or splintering of the wood.

HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.

For certification use only
Factory table ID # HUC32451 Factory chair ID # HUC39240