



PROLINE

PROFESSIONAL QUALITY RANGE HOODS

Care and Maintenance of your Proline Range Hood

What's the best way to clean my range hood?

Use warm water and mild soap in the direction of the polish lines regularly to clean the outside of your range hood. Rinse well with clear clean water and wipe dry immediately. For additional shine, you can apply a little coconut oil. Don't use harsh or abrasive cleaning agents on your hood.

How often should I clean my range hood's filters?

The steel baffle filters and aluminum mesh filters are completely dishwasher safe for easy cleaning. Clean them approximately every two weeks to a month depending on usage. Wash more often if your cooking style generates greater grease like frying foods or wok cooking. You cannot clean/wash the non-ducted carbon filters; they must be replaced.

How often should I replace my range hood's charcoal filters?

With normal average cooking, you should replace your charcoal filters every three (3) to six (6) months, or if the air around the cooktop stops smelling clean when in use.

Additional Info

We also have videos on additional topics on our website and youtube channel like these:
(click on the titles below to see the videos)

- [How to Replace a Range Hood Control Panel](#)
- [How to Remove Scratches from Your Range Hood](#)
- [How to Clean Stainless Steel Range Hoods](#)
- [How to Disassemble your Range Hood](#)
- [How to Clean Baffle Filters and Range Hood Fans](#)
- [How to Change the Charcoal Filters on a Ductless Hood](#)
- [How to Replace Your Range Hood Lightbulbs](#)

For warranty service, or any questions, please contact Proline Range Hoods at:
1-877-901-5530 or support@prolinerangehoods.com or visit www.prolinerangehoods.com