


QUICK START INSTRUCTIONS

Item #28088 – BLUETOOTH & HDMI


1. Power on projector.
2. Select Movie. Press “OK” on remote or projector.




3. Select **PreLoaded**. Press “OK” on remote or projector.





4. Select either Vertical or Horizontal to view videos. Press “OK” on remote or projector.





5. Select Christmas or Halloween folder for videos. Press “OK” on remote or projector.



6. Press “PLAY”  on remote or projector to play all videos OR Press “OK” on files to select preferred videos to view.




For **HDMI** – Press the Input/Source  button on remote or projector and select HDMI.



For **BLUETOOTH**

1. Press MENU on remote or projector and scroll to find the SOUND menu. Scroll to “Bluetooth” and select “ON.”



2. To pair Bluetooth device, click “SEARCH” to locate Bluetooth device. Make sure Bluetooth device is turned on and in pairing mode.



3. Once paired, select Bluetooth device and press “OK” on remote or projector.



STOP! Before you return to store.

Our team of experts will answer
any questions.
Call 1-888-476-7100