


EXPLODED VIEW



PARTS LIST

Number	Stock#	Description	QTY.
1	PS2028-001	METAL HANDLE LEFT FIXING BLOCK (FOR GUN)	1
2	PS2028-002	BRASS CONNECTOR	1
3	PS2028-003	LEFT HOSE REEL	1
4	PS2028-004	HIGH PRESSURE HOSE L=8000	1
5	PS2028-005	RIGHT HOSE REEL	1
6	PS2028-006	METAL HANDLE RIGHT FIXING BLOCK (FOR HANDLE)	1
7	PS2028-007	HANDLE FOR HOSE REEL	1
8	PS2028-008	HANDLE KNOB FOR HOSE REEL	1
9	PS2028-009	METAL HANDLE SEAT	1
10	PS2028-010	EXTRUSION PROFILES FOR HANDLE	2
11	PS2028-011	SCREW 3,9x22	17
12	PS2028-012	METAL HANDLE BRACKET	1
13	PS2028-013	HIGH PRESSURE HOSE L=750	1
14	PS2028-014	WHEEL COVER	2
15	PS2028-015	WHEEL	2
16	PS2028-016	BACK CABINET	1
17	PS2028-017	MOTOR CONVEYOR	1
18	PS2028-018	MOTOR	1
19	PS2028-019	GEAR Z22	2
20	PS2028-020	PLANET SUPPORT	1
21	PS2028-021	OUTSIDE GEAR Z56	1
22	PS2028-022	ALUMINUM FLANGE	1
23	PS2028-023	THRUST BEARING 45x62x11	1
24	PS2028-024	WOBBLE PLATE 8.2°	1
25	PS2028-025	THRUST BEARING 35X55X12	1
26	PS2028-026	SCREW 5.5*25	4
27	PS2028-027	RETAINING RING D.21	3
28	PS2028-028	PISTON SPRING	3
29	PS2028-029	PISTON	3
30	PS2028-030	O-RING 62X2.1	1
31	PS2028-031	CHECK VALVE ASSEMBLY	1
32	PS2028-032	RING X VALVE GUIDE	1
33	PS2028-033	BODY GUIDE	1
34	PS2028-034	TOTAL STOP SWITCH	1
35	PS2028-035	INLET PIN	1
36	PS2028-036	INLET PLASTIC JOINT	1
37	PS2028-037	OIL SEAL	3

38	PS2028-038	RING FOR SUPPORT SEAL	3
39	PS2028-039	WATER SEAL	3
40	PS2028-040	SUCTION VALVE	3
41	PS2028-041	SEAL GASKET	1
42	PS2028-042	PARTNER HEAD	1
43	PS2028-043	DELIVERY VALV.CAP	3
44	PS2028-044	DELIVERY VALVES	3
45	PS2028-045	SCREW M6*60	4
46	PS2028-046	SCREW 3,9x22	2
47	PS2028-047	FIX PAD	1
48	PS2028-048	USA PLUG	1
49	PS2028-049	SCREW 3,9x22	2
50	PS2028-050	COVER FOR ELECTRICAL BOX	1
51	PS2028-051	ROTARY SWITCH	1
52	PS2028-052	FRONT CABINET	1
53	PS2028-053	FRONT PAD	1
54	PS2028-054	SWITCH KNOB	1
55	PS2028-055	NOZZLE KIT	1
56	PS2028-056	LANCE	1
57	PS2028-057	GUN	1
58	PS2028-058	PIN FOR NOOZLE	1