
Item # 1005 442 744 Model # FRS60704L-BA

HAMPTON BAY

GENEVA WOVEN LOVESEAT - BARE



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this loveseat. We strive continually to create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents
Important Safety Instructions
Save These Instructions
Read All Instructions before Use
Warranty 3
What is covered
What is not covered 3

Pre-Assembly	. 3
Planning Assembly	. 3
Hardware Included	. 4
Package Contents	. 4
Assembly	5
Care and Cleaning	

Important Safety Instructions

SAVE THESE INSTRUCTIONS

WARNING: THIS LOVESEAT WAS MADE FOR THE EXPLICIT PURPOSE OF PROVIDING OUTDOOR FUNCTIONS AND IS NOT TO BE USED AS A TOY. THIS PRODUCT IS INTENDED FOR NORMAL OUTDOOR USE; HOWEVER, THE MANUFACTURER RECOMMENDS STORING AND/OR COVERING THIS PRODUCT WHEN ANY FORMIDABLE/SEVERE WEATHER IS APPROACHING.

WARNING: DO NOT LOCATE THIS PRODUCT NEAR OPEN FLAMES. DO NOT USE THIS PRODUCT AS A SUPPORT. DO NOT SHAKE, LEAN OR CLIMB ON THE PRODUCT. CHILDREN UNDER THE AGE OF 10, NEAR THE PRODUCT, SHOULD BE SUPERVISED BY A COMPETENT ADULT AT ALL TIMES. THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE AND WILL VOID THE WARRANTY.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Do not move the loveseat while it is occupied. Failure to obey this caution could result in injury.
- 4. Do not rock in the loveseat as you may fall and cause serious injury.
- 5. Please keep children out of the assembly area before assembly.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat sources.



WARNING: Weight limit for the loveseat is 250lbs (113.39Kg) for each seat.



WARNING: This loveseat unit is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the loveseat.

3 YEAR FRAME LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HAMPTONBAY.com.

Pre-assembly

PLANNING ASSEMBLY


Read all instructions before assembly. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.


Pre-assembly (continued)

HARDWARE INCLUDED



Part	Description	Quantity
AA	M6x15 Combination Bolt	10+1
BB	Hex Wrench	1

PACKAGE CONTENTS



Part	Description	Quantity
Α	Right Arm	1
В	Left Arm	1
C	Seat	1
D	Back	1
E	Back Cushion	2
F	Seat Cushion	2


Assembly

79

Attaching The Seat To The Back

NOTE: Loosely tighten all bolts using the hex wrench (BB).


- □ Place the seat (C) and the back (D) on a soft surface.
- □ Attach the seat (C) to the back (D) using M6x15 combination bolt (AA).





NOTE: Loosely tighten all bolts using the hex wrench (BB).

- □ Place the left arm (B) upside down on a soft surface.
- □ Attached the seat (C) to the left arm (B) using M6x15 combination bolts (AA).




Assembly (continued)

79

Attach The Seat To The Right Arm

NOTE: Loosely tighten all bolts using the hex wrench (BB).


- □ Place the right arm (A) upside down on a soft surface.
- □ Attached the seat (C) to the right arm (A) using M6x15 combination bolts (AA).



Attach The Left And Right Arms To The Back

NOTE: Loosely tighten all bolts using the hex wrench (BB).

- □ Turn the loveseat right side up.
- □ Attach the left arm (B) and the right arm (A) to the back (D) using M6x15 combination bolts (AA).




Assembly (continued)

5

Tightening All The Bolts

- □ Once all of the bolts are in place, fully tighten all the bolts using hex wrench (BB).
- $\hfill\square$ Place the seat cushion (F) and back cushion (E) on the loveseat.
- □ Ensure all connections are secure before use.



Care and Cleaning

- □ For best results, clean the frame and fabric with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach or solvents.
- □ Store the loveseat in a dry sheltered place when not in use.
- □ Keep the loveseat away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.

For certification use only

Factory Loveseat ID # FRS60704L