


PARTS



PART NAME

PART NUMBER

1	Top Vent	VGCTV-CA
1.1	Aluminum Tab with Silicone Outer Coating	VGCTV-CA-ATSC
2	Ceramic Dome Top	VGKPCDL-2
3	Top Ring Assembly	VGKPPRA-B1
4	Fire Bowl	VGKPPFP-1
5	Bottom Ring Assembly	VGKPPRA-B2
5.1	Right Front Side Shelf Bracket	VGKPPSB-RF
5.2	Right Back Side Shelf Bracket	VGKPPSB-RB
5.3	Left Front Side Shelf Bracket	VGKPPSB-LF
5.4	Left Back Side Shelf Bracket	VGKPPSB-LB
6	Shock Absorber Assembly	VGCAAC-L
7	Wood-Sculpted Thermoplastic Side Shelves with Accessory Hooks (x2)	VGKPPTPSS-R/L
8	Charcoal Grate	VGKPPCG-L
9	Ceramic Dome Bottom	VGKPPDB-B
10	Bottom Draft Door Frame	KSSBD-1
11	Bottom Draft Door	KSSBD-2
12	Cart Legs (x4)	VGCSPCLEG-4
13	X Leg Connector and Washers (x2)	VGCLXC-L
14	Thermometer	VGKPPMT-1
15	Handle	VGKPPHDL-1
16	Cooking Grid	VGKPPCGD-1
17	Rubber Wheels (x2) Locking	VGCVHLL-L2
18	Rubber Wheels (x2) Standard	VGKPPWHL-4
19	Felt Gasket	VGKPPFLT-1