




Equipment Sizing Guide



Use the map above to determine your region and compare to the chart below to find your application size.

80% AFUE Gas Furnace (Multi-Positional) Selection

Square Footage	Region 1	Region 2	Region 3	Region 4	Region 5	Furnace Size
624-780	675-840	750-940	915-1140	1025-1280	1280-1925	40,000 BTU
780-1170	840-1260	940-1410	1140-1710	1280-1925	1925-2550	60,000 BTU
1170-1560	1260-1680	1410-1880	1710-2280	1925-2550	2550-3200	80,000 BTU
1560-1950	1680-2100	1880-2350	2280-2850	2550-3200	3200-3850	100,000 BTU
1950-2340	2100-2525	2350-2825	2850-3425	3200-3850		120,000 BTU

Residential Sizing: The table and charts are intended to be used as a guideline for Residential applications only. The information is based on conventional window space (<15%), insulation and building construction (8 ft. ceiling height). When including a finished basement, use 1/2 of the finished basement square footage with the rest of the area being calculated.

Mobile/Manufactured Home Sizing: Refer to the Date Plate located in the electrical box or kitchen cabinets. For further assistance, call Hamilton's customer service department (800) 879-0123.