

Bronzed Living Surfaces



For best results, keep the following in mind when caring for your KOHLER® product:

- Always test your cleaning solution on an inconspicuous area before applying to the entire surface.
 - Wipe surfaces clean and rinse completely with water immediately after applying cleaner. Rinse and dry any overspray that lands on nearby surfaces.
 - Do not allow cleaner to soak.
 - Use a soft, dampened sponge or cloth. Never use an abrasive material such as a brush or scouring pad to clean surfaces.
 - For warranty information call 1-800-4KOHLER (1-800-456-4537).
* Success with cleaners and procedures is dependent upon such factors as the hardness and temperature of the water, using exact measurements of ingredients, changes in cleaning formulas and the condition of the product being cleaned. Since there are variations within these factors, Kohler cannot guarantee the effectiveness of the formulas.
-

- Bronze is easily scratched. Avoid contact with metal objects.
- Keep the basin clean and dry by wiping with a soft cloth after use.
- Clean with water and a VERY SMALL amount of dishwashing soap. Never use abrasives, metal polishes or lime/rust removal products.
- Do not allow toothpaste, carbonated beverages or other household products to rest on the surface for a prolonged period of time.
- Apply a temporary protective coating of carnauba-based paste wax when you notice that water no longer forms beads on the surface.

- Kamala Recovery Cleaner Kit may be purchased online to restore the original finish.

Success with cleaners and procedures is dependent upon such factors as the hardness and temperature of the water, using exact measurements of ingredients, changes in cleaning formulas and the condition of the product being cleaned. Since there are variations within these factors, Kohler cannot guarantee the effectiveness of the formulas mentioned.