

Frigidaire[®]

FRIGIDAIRE RETRO SQUARE SMOOTHIE MAKER



ESMM100

Instructions

FRIGIDAIRE is a pending or registered trademark used under license from Electrolux Home products, Inc.

For service assistance and product information, please call: 1-800-968-9853.

Curtis International Ltd.

7045 BECKETT DRIVE, UNIT 15, MISSISSAUGA, ON, L5S 2A3 www.curtisint.com

Content

SAFETY PRECAUTIONS.....	1&2
SKETCHES.....	2
OPERATIONAL GUIDELINES.....	3
OPERATIONAL STEP	3&4
CARE AND MAINTENANCE	4&5
DISPOSAL.....	5
SPECIFICATIONS.....	5

Safety Precautions

Please read these instructions carefully prior to using this machine and follow to operate.

Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.

This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.

Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.

Children shall not play with the appliance.


This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.

CAUTION: Ensure that the blender is switched off before removing it from the stand. Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.

1. Check whether the voltage you use is consistent with the voltage on the product nameplate.
2. Please don't hang the power cords on the edge of the table or surface.
3. Please don't place the machine on hot surfaces, or near the flammable gases and electric stoves, etc.
4. If the power supply flexible cable is damaged, it must be replaced by the manufacturer, an authorized maintenance department or a similar professional personnel in order to avoid danger.
5. The work of cleaning and maintaining the appliances should not be carried out by children if there is no supervision.
6. Don't allow the children to play with this appliance.
7. Don't touch the blade before that part stop operation.
8. Be careful not to cut by the blade during the installation, removal and cleaning.
9. Please don't use non manufacturers accessories .
10. This machine is unable to stir the hard or dry food to avoid passivation of knives.
11. Please disconnect the power when not using or before cleaning the machine.
12. Do not immerse the main body in water or other liquids to avoid the electrical shock.
13. Don't use outdoors.
14. When the machine is working, do not put your hands or other utensils into the juice cup.
15. To avoid the occurrence of danger, please make sure that the cup is installed correctly before installing the mixing assembly to the main machine.
16. Please make sure the lid is installed property before operating the machine.
17. The products and power cords should be stored in a safe place to avoid the power cords are pulled by children.

18. Warning: Do not use the hot liquids or leave the machine working idly.
19. Please keep this manual properly for reference in the future.

Sketches



Check whether the parts used are complete and the mainframe is in good condition. And then Add few water to the accompanied cup, Operate once or twice according to the following operating guidelines. Pour out the water and clean the accompanied cup and lid thoroughly with warm water.

Warning: The blade is very sharp. Please be careful.

Operational guidelines

1. Place the main body on a flat table. Make sure the power cord is not plugged into the socket.

2. Place the accompanied cup on a flat table with rim facing upwards. Put the ingredients your have prepared in the cup, and the ingredients must not exceed the reference line of 500ml.

Note: This machine has the function of breaking ice, you can add the appropriate amount of ice in the cup as needed.

Note: In order to obtain the best results, please add the ingredients to the cup as per the following order: Liquid, fresh ingredients, frozen fruit, yogurt and ice cream.

3. Peel or kernel fruits or vegetables, and cut them into small pieces.

Note: Do not use the boiling liquid, do not let the machine working idly.

4. Install the cup seat clockwise on the opening of the accompanied cup.

5. Reverse the portable cup and cup seat, install them into the main machine and ensure the arrow of main machine aligning with the arrow on the cup seat. Then rotate the cup seat clockwise to lock it tightly.

6. Turn on the power, pull down the switch and the machine starts to work.


Note: The machine can work continuously for up to 1 minutes and then need to cool down to the room temperature.

7. After completing the operation, rotate the cup assembly counterclockwise to disassemble it, the machine stops running and then the power supply is unplugged.


8. Reverse the cup assembly and spin down the cup seat.

9. Cover the lid on the cup body. Unplug the power.


Operational Step



1. Put the water, milk and the appropriate amount of fruit and vegetable with proportion into the glass.



2. Fasten the blade assembly to the container, connect the power cord of the main machine and turn on the power supply. Align the vessel with the interface of main machine. Rotate clockwise to fasten, the READY lamp is on to indicate the installation has been completed.



3. Pull the lever downwards, the indicator lights jump to START-UP and the motor starts working. (Note: Single stirring time should not exceed 1 minutes). Remove the cup after juicing, after unplugging the power to replace lid, it can be taken away or used after inserting a straw.

Care and maintenance

Note :

- Switch the blender off by turning the knob to off and unplug it before cleaning it. Exercise extreme caution. Take care when handing the blade unit -the blades are extremely sharp.
- Never immerse the motor unit into water. Wipe the outside of the motor unit with a clean,damp cloth.
Generally, Do not run the appliance for more than 1 minute at once. Allow the appliance to cool for at least 5 minutes every time it has been used for 1 minute. This can be repeated 3 times. Allow the appliance to cool afterwards to room temperature before using again.

Cleaning the jug with the blades fitted

Empty the cup, fill it with water, add a little washing-up liquid(not exceed 8 OZ). Put the cup back onto the machine's principal and turn the switch on about 15 seconds. Operate the blender until you are satisfied that any food residue has been washed

off the sides of the cup and then empty the dishwasher out of the cup. Rinse the cup with clean water and let it dry.

Cleaning with the blades removed

1. Turn the cup upside down and remove the cup base by turning it counter-clockwise.
2. Lift out the gasket, and wash all the parts.
3. Let the parts air dry before re-assembling them in the jug .Refer to the picture in the Product description section to ensure that the seal is fitted correctly.

Note: ALL parts must be washed by hand.

Switch the blender off, unplug the mains lead from the wall socket and store the cleaned blender in a dry, dust-free place out children’s reach whenever it is not to be used for any extended period.

Disposal

This product should be disposed of in accordance with local regulations .
If you are unsure how to proceed, contact your local council.



■ This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Specifications

Mains supply	120V , 60Hz, CLASS II
Wattage	300W
Max operating time	1minutes continuously, then the motor should be allowed to cool down the room temperature.