
INSTRUCTIONMANUAL



Pleasekeepthismanualandproductcodenumberforfuturereference andfororderingreplacementpartsifnecessary.

GENERAL INSTRUCTIONS

- Read this manual carefully and completely before proceeding.
- It is recommended that you wear safety glasses at all times during the installation.

INSTALLATION OVER CERAMIC TILES

- If your shower door is to be installed over ceramic tiles, the tiles should lay completely under the wall jamb.
- Silicone should be used to seal the gap where the ceramic tiles meet the fixed panel.


NOTICE

- Caulking : no sealant is required inside the shower, unless otherwise stated.
- Some models are equipped with clear sealing gaskets.


CARE FOR YOUR SHOWER DOOR

- Never use scouring powder pads or sharp instruments on metal pieces or glass panels.
 An occasional wiping down with a mild soap diluted in water is all that is needed to keep the panels andmetal parts looking new
- We recommend wiping the glass panels with a squeegee after each use.

Tools Required



Detailed Diagram of Shower Enclosure Components



NO.	Name	Picture	Qty	NO.	Name	Picture	Qty
1	Ø60 Roller	•	4	9	Sliding door		2
2	Guide Rail	Ħ	1	10	Anti-splash threshold		1
3	Anti jumping knob	SF05-20-15	4	11	screw ST4x30	* @	1
4	Wall bracket		2	12	6mmWall plug		1
5	8mmWall plug		4	13	Guide block	₩ E ₩° GU02-82	1
6	screw ST5x40	0	4	14	Anti Collision Block		4
7	Door seal		2	15	Door seal		2
8	Towel bar		2				

