



## **DocaPole 30ft Ceiling Flex Fan Duster Assembly Instructions**

- 1. To adjust extension pole length, raise thumb levers and pull out pole segments to desired length, then lower thumb levers to lock into place**
- 2. Use the plastic hinge tip as needed to adjust the angle of the desired attachment. Simply screw the female plastic hinge tip directly onto the male metal tip of the pole, then screw your attachment onto the angled hinge tip (make sure it is locked into place by turning the dial on the side).**
- 3. Screw the Ceiling Flex Fan Duster directly onto the Metal Tip of the Pole (remember to unscrew the cap at the base of the duster). If you need the duster to be at an angle, use the included plastic Hinge Tip and adjust the angle as needed. The Duster is meant to be bent and shaped as needed to fit the dusting job at hand.**
- 4. Enjoy your DocaPole and Ceiling Flex Fan Duster!**