

User Manual for Portable Mini Fridge

Product Overview:

This user manual is designed to guide you through the safe and efficient operation of your portable mini fridge. Our mini fridge features advanced temperature control, colorful LED lighting, and versatile power options, making it an ideal companion for homes, offices, cars, and more.

Unpacking and Setup:

Unpack Carefully: Remove the mini fridge from its packaging and inspect for any damage.

Choose Your Power Cord: Decide whether you will be using the AC-110V household power cord or the DC-12V car power cord. Connect the appropriate cord to the back of the fridge.

Position the Fridge: Place the fridge on a flat, stable surface, ensuring good ventilation around it.

Adjust Shelves (If Applicable): If your fridge comes with adjustable shelves, arrange them according to your storage needs.

Operation:

Power On: Plug the power cord into a suitable outlet and turn on the fridge using the power switch located on the back or side.

Set Temperature: Use the temperature control buttons or dial to set your desired temperature. For cooling, adjust it below the ambient temperature; for heating, set it to the desired warm temperature range.

LED Lighting: To change the LED lighting color, simply tap the sensor near the door. The seventh tap cycles through all colors, and a long press turns off the lights.

Maintenance:

Cleaning: Wipe the exterior of the fridge with a damp cloth. Avoid using abrasive cleaners or spraying water directly onto the fridge.

Defrosting (If Necessary): If the fridge accumulates frost, turn it off and allow it to defrost naturally. Wipe away any remaining moisture with a dry cloth.

Check Power Cord: Regularly inspect the power cord for signs of wear or damage, and replace if necessary.

Safety Precautions:

- Do not place the fridge near heat sources or in direct sunlight.
- Ensure the fridge is properly ventilated to prevent overheating.
- Avoid overloading the fridge with items that exceed its capacity.
- Do not attempt to modify or disassemble the fridge.
- Unplug the fridge before cleaning or performing any maintenance.

Troubleshooting:

If the fridge does not cool or heat properly, check that the power cord is securely connected and that the temperature settings are correct.

If the LED lights do not function, ensure the fridge is powered on and try tapping the sensor again.