

Automatic Foam Soap Dispenser Manual

Installation Guide

1. Take out the white giraffe-shaped foam soap dispenser and accessories from the package (magnetic charging cable is sold separately).
2. Open the tank lid, pour foam hand soap into the 300ml (10oz) transparent water tank, and close the lid tightly.
3. Place the dispenser in a suitable position (bathroom, kitchen), ensuring the infrared sensor is unobstructed and away from direct water flushing.
4. If the device is out of power, use a magnetic charging cable to charge it; after charging, place it back to the desired position and it is ready for use.

Instructions / Assembly

This is a white, giraffe-shaped touchless automatic foam soap dispenser, 300ml (10oz), with 3 adjustable foam gears, IPX5 waterproof, rechargeable and equipped with LED timer.

1. Assembly: No complex assembly needed; just add foam hand soap to the tank and power on the device.
2. Touchless Operation: Put your hand under the infrared sensor, and it will spray dense foam in 0.2 seconds without contact.
3. Foam Adjustment: There are 3 foam modes (low/medium/high) to meet different cleaning needs, with soap-saving function to reduce waste.
4. LED Timer: The 15-second flashing LED light helps children master the ideal hand-washing time, making hand-washing fun.

Use and Care Manual

1. Usage Notes: Only use foam hand soap; check the liquid level at any time through the transparent tank and add soap in time.
2. Waterproof Care: IPX5 waterproof shell resists daily splashing; do not flush the device directly with water.
3. Charging Care: Built-in 1200mAh battery, 90-day long battery life after full charge; magnetic charging cable is sold separately.
4. Daily Care: Wipe the dispenser surface with a soft cloth regularly; keep the sensor clean and unobstructed to ensure normal operation.
5. Maintenance: Avoid dropping or collision; if the dispenser fails to spray foam, check the liquid level and sensor, and charge it if necessary.