


ASSEMBLY INSTRUCTIONS

Item #: L-BR094PGR-2




Congratulations on your purchase of our SUNJOY Baker's Rack. Our clear, easy to follow, step-by-step instructions will guide you through the assembly process from start to finish.

WARNING:

- Read and follow all Warnings & Assembly Instructions before attempting to assemble.
- Begin assembly not less than 6 feet from any obstruction such as a fence, garage, house, overhanging branches, laundry line, or electrical wires.
- Some parts may contain sharp edges. Wear protective gloves as necessary.
- Keep children away from assembly area.
- Assemble on level ground.
- Do not over tighten any of the bolts or nuts, but do tighten each bolt and nut until firm.
- Check all nuts and bolts for tightness before and during usage.
- This unit is heavy. Do not assemble this item alone.

Parts List




No.	Name	Qty.
A	Top Panel	1
B	Top shelf	1
C	Middle shelf	1
D	Lower panel	1
E	Lower shelf	1
F	Support	2
G	Base shelf	1
H	Leg	2
I	Support	2
AA	Bolt M6*50	2
BB	Bolt M6*45	8
CC	Bolt M6*35	6
DD	Bolt M6*15	8
EE	Bolt M6*20	14
FF	Flat Washer M6	38
GG	Split washer M6	38
HH	Nut M6	16
II	Wrench M6	2
JJ	Ground Stakes D8*250	2



Assembly instruction: (Tool Needed: Wrench

HH)


Step 1



Insert Top Panel A into Lower Panel D, tighten with bolts DD, flat washer FF and split washer GG from the side direction and connect with bolts AA, flat washer FF, split washer GG and Nut HH from the vertical direction (Fig 1.1).


Attach supports F to Lower Panel D, tighten with bolts EE, flat washer FF and split washer GG. (Fig 1.2)

Step 2




Attach Base Shelf G to Lower Panel D; tighten with bolts BB, Flat Washer FF, Split washer GG and Nut HH.

Step 3



Attach Legs H to Base Shelf G, tighten with bolts EE, flat washer FF and split washer GG.

Step 4




Insert Lower Shelf E into the slots on Leg H.

Attach Lower Shelf E to Top Panel A; tighten with bolts BB, flat washer FF, split washer GG and Nut HH.

Attach Lower Shelf E to Lower Panel D; tighten with bolts BB, flat washer FF, split washer GG and Nut HH. (Fig.4.1)


Attach Lower Shelf E to Leg H by using bolts EE, flat washer FF, and split washer GG (Fig.4.2)

Step 5



Attach Support I to Middle shelf C, tighten with bolt EE, flat washer FF, Split washer GG (Tool needed: II)


Step 6



Attach Middle shelf C to Top Panel A, tighten with bolts CC, flat washer FF, split washer GG and Nut HH. (Fig.6.1)

Attach support I to Top Panel A, tighten with bolt EE and flat washer FF, Split washer GG. (Fig.6.2)

Step 7



Attach Top Shelf B to Top Panel A; tighten with bolts CC, flat washer FF, split washer GG and Nut HH. (Fig.7.1)

Secure the completely assembled Baker's Rack into the ground by using the Ground Stakes JJ. (Fig.7.2)

Limited Warranty:

Sunjoy Industries warrants to the original purchaser that this item is free from defects in workmanship and materials for a period of 6 months from the date of purchase, provided the item was factory-sealed at the time of purchase and is maintained with care and used only for personal, residential purposes. Should any manufacturing defect arise within this warranty period, Sunjoy Industries will repair or replace (at our option)

any defective merchandise upon proof of purchase; however, transportation and delivery costs, as well as payments to a third party for assembly or disassembly of the item, remain the responsibility of the purchaser. A purchaser of an "open box," previously-returned, or "clearance" item, as well as original purchasers outside of the warranty period, may obtain replacement parts from Sunjoy Industries for products in current production, at nominal cost.

Exclusions:

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.