

Assembly & Instructions – Telescopic Ratchet Anvil Loppers

Assembly Instructions:

1. Remove the loppers from the packaging and ensure all components are included.
2. Unlock the safety catch to release the blades before use.
3. Adjust the telescopic handles by unlocking the extension locks. Extend the handles to the desired length between 28 in. (710 mm) and 40.5 in. (1030 mm).
4. Once extended, securely lock the handles in place to ensure stability during use.
5. Confirm the ratchet mechanism is working smoothly by lightly pressing the handles together before attempting to cut.

Usage Instructions:

- Place the blade around the branch you want to cut, positioning it close to the pivot for maximum leverage.
- Apply pressure to the handles in short, firm steps to activate the ratchet mechanism, allowing easy cutting of thicker or harder branches.
- Use the telescopic handles for added reach when cutting higher or deeper branches.
- The SK5 carbon steel blade with PTFE coating ensures sharpness and rust resistance for smooth, clean cuts.

Safety & Maintenance:

- Always wear protective gloves and safety glasses when cutting branches.
- Store the loppers with the safety catch locked to prevent accidental injury.
- Keep the blades clean and dry after each use to maintain sharpness and rust resistance.
- Periodically oil the pivot and ratchet mechanism to ensure smooth operation.
- Do not exceed the maximum cutting capacity to avoid damaging the tool.