

LG WashTower™ Pre-Delivery Cheat Sheet

STEP 1 | Watch the Measure First Video

The video explains how to **Walk the Path** to ensure the unit will fit through doorways and can be properly moved into the designated space. It also covers how to determine fuel type and required accessories.





STEP 2 | Confirm the Customer's Fuel Type

Gas Requirements





Electric Requirements





IMPORTANT! For Electric Dryers, customers need to know whether they have a **3-prong or a 4-prong outlet** to purchase the correct cord. Most electric power cords are 4-6 ft long. Be sure to purchase a cord long enough to reach from the top of the dryer to the outlet.

STEP 3 Confirm All Required Accessories Have Been Purchased

Click your Model type to view required accessories and the Customer Checklist.

Gas Models

With Steam Dryer

WKGX201HBA WKGX201HWA WSGX201HNA

Without Steam Dryer

WKG101HVA WKG101HWA

Electric Models

With Steam Dryer

WKEX200HBA WKEX200HWA WSEX200HNA

Without Steam Dryer


WKE100HVA WKE100HWA



LG WashTower™ Customer Checklist

Models

- WKG101HVA
- WKG101HWA





1 | Measure First & Confirm Fuel Type

- Watch Measure First Video
- ☐ Confirm 120V, 15-Amp Outlet (For Washer)
- ☐ Locate the Gas Line and Shut Off Valve
- ☐ Find the Water Line and Shut Off Valve





2 | Purchase Required Accessories

IMPORTANT! These accessories are sold separately and are required for proper installation.







3 | Follow Delivery Day Install Steps

- Install Gas Line
- 2 Install Ducting for Exhaust Vent Outlet
- 3 Install 2 Hoses for Hot and Cold Water Inlets and Dryer for Steam
- 4 Plug 2 power cords for both Washer & Dryer into 120V, 15-Amp Outlet*
- 5 Remove 4 Shipping Bolts prior to Installation
- 6 Install Drain Hose
- 7 Activate Proactive Customer Care

 Download the LG ThinQ® App to activate Proactive Customer Care.