

24.6 IN. STEEL ROUND

ITEM #1005 586 728 1005 586 734 1005 586 732 MODEL #FTS41037-Peony FTS41037-Bre FTS41037-Gray


FOLDING BISTRO TABLE STYLEWELL

Use and Care Guide

Operation


OPENING THE TABLE

Slide the table top upwards until the legs fully extend outward and latch the hook to the legs.



FOLDING THE TABLE

Unlatch the lock, slide the table top downwards until the legs collapse.



Safety Information



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the table top.

Care and Cleaning

- For best results, clean the frame with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach, or solvents.
- Store the table in a dry, sheltered place when not in use.
- Keep the table away from fire, extreme heat, freezing conditions, and inclement weather such as rain, sleet, snow, or wind.

Warranty

1 YEAR FRAME WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make subsitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-877-527-0313 or visit www.HomeDepot.com.