

# CARING FOR METAL FURNITURE



## REGULAR CLEANING

Dust your metal furniture frequently with a dry, clean cloth to remove surface dirt and debris. For more thorough cleaning, use a solution of mild soap and warm water. Dip a soft cloth or sponge in the soapy water and gently scrub the metal surfaces. Rinse with clean water and dry thoroughly.



## HARDWARE CHECK

Periodically inspect and tighten any screws, bolts, or other hardware to ensure the stability of your metal furniture. Loose connections can lead to wobbling or instability.



## PREVENT SCRATCHES

Be mindful of sharp or heavy objects that could scratch the metal surface. Use coasters or placemats to protect tabletops and avoid dragging items across metal surfaces.



## UPHOLSTERED AND PADDED METAL FURNITURE

If your metal furniture has upholstered or padded parts, when spills occur, clean them promptly with a damp, soft cloth. Avoid using harsh chemicals or abrasive materials. For tougher stains, mix a mild solution of water and a few drops of gentle liquid soap. Dampen a cloth with this solution and gently wipe the stained area. Always test a small, inconspicuous spot first to ensure the cleaner doesn't damage the material.



## AVOID HARSH CHEMICALS

Refrain from using abrasive or harsh chemical cleaners on metal furniture, as these can damage the finish. Stick to mild soap and water solutions or metal-specific cleaning products.

Metal furniture is not only durable and versatile but can also add a sleek and modern touch to your indoor or outdoor space. To keep your metal furniture looking its best and to extend its lifespan, follow these essential care and maintenance tips:

With proper care and attention, your metal furniture can remain in excellent condition, offering both aesthetic appeal and functionality for years to come. Always refer to the manufacturer's care instructions for specific guidance on caring for your particular type of metal furniture.

# CARING FOR WOOD FURNITURE

Wood furniture adds warmth and character to your home but requires proper care to maintain its beauty and durability. Follow these essential tips to ensure your wood furniture remains in excellent condition for years to come:



## REGULAR DUSTING

Dust your wood furniture regularly with a soft, dry cloth or a microfiber duster. This prevents the buildup of dust and particles that can scratch the wood's surface.



## USE COASTERS AND MATS

Place coasters or placemats under hot and cold beverages, dishes, and flower vases to prevent heat rings and water stains on wooden surfaces.



## GENTLE CLEANING

Use a mild, non-abrasive wood cleaner or a mixture of mild dish soap and water for regular cleaning. Dampen a soft cloth with the solution, wipe the surface, and dry it thoroughly.



## AVOID DIRECT SUNLIGHT

Position your wood furniture away from direct sunlight or use window coverings to protect it. Sunlight can cause fading and drying out of the wood over time.



## WIPE SPILLS PROMPTLY

Accidents happen. When spills occur, wipe them up immediately with a clean, slightly damp cloth to prevent staining and warping.



## REPAIR SCRATCHES AND DENTS

Use a wood touch-up pen or wax stick that matches the furniture's finish for minor scratches. For deeper scratches or dents, consult a professional furniture repair expert.



## AVOID HARSH CHEMICALS

Please refrain from using abrasive cleaners, ammonia-based products, or harsh chemicals on your wood furniture, as they can strip the finish or damage the wood.



## HANDLE WITH CARE

Lift and move furniture items rather than dragging them, as this can cause scratches and damage to the furniture and the floor.



## GENTLE STORAGE

If you need to store wooden furniture for an extended period, do so in a climate-controlled environment to prevent warping or cracking.

**By following these care and maintenance guidelines, you can ensure that your wood furniture continues to enhance your living space with its timeless charm and elegance.**