Assembly Instruction

ITEM N0.:8517BRW/GRY-2
Double Reclining Love Seat with
Center Console




Hardware are stored at the bottom of sofa, please take out it for assembly hardware for assembly.


Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to spliting or cracking the wood.

Component list


No	Drawing	Qty	Description
A		1	SEAT
В		1	LSF BACK REST
С		1	CONSOLE BACK REST
D		1	RSF BACK REST
E		2	STAR KNOB


Step #1






Step #2







Care Instruction for Polished Microfiber Fabric Furniture:

In order to maintain the original appearance of your Polished Microfiber Fabric Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Polished Microfiber Fabric.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.

Assembly Instruction

ITEM No.: 8517BRW/GRY-3 Double Reclining Sofa




Hardware are stored at the bottom of sofa, please take out it for assembly hardware for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to spliting or cracking the wood.


Component list


No	Drawing	Qty	Description
A		1	SEAT
В		1	LSF BACK REST
С		1	MIDDLE BACK REST
D		1	RSF BACK REST

Step #1



Step #2





Care Instruction for Polished Microfiber Fabric Furniture:

In order to maintain the original appearance of your Polished Microfiber Fabric Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Polished Microfiber Fabric.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.