


Item #1000 000 000
Model #LG1259-9PC-2PK

HAMPTON BAY®

USE AND CARE GUIDE

Crenshaw Park 2 -Pack Dining Chairs



**Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday**

**1-855-HD-HAMPTON
HAMPTONBAY.COM**

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of these dining chairs. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2	Pre-Assembly.....	3
Important Safety Instruction.....	2	Planning Assembly.....	3
Save These Instructions.....	2	Hardware Included.....	3
Read All Instructions Before Use.....	2	Chair Package Content.....	4
Warranty.....	3	Chair Assembly.....	5
What is Covered.....	3	Care and Cleaning.....	6
What is not Covered.....	3		

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: These chairs were made for the explicit purpose of providing outdoor functions and are not to be used as a toy. This product is intended for normal outdoor use; the manufacturer recommends storing and / or covering this set when any formidable. / Severe weather is approaching.



WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
2. Use this product only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Do not move the chair or table while they are occupied. Failure to obey this caution could result in injury.
4. Do not rock in the chair or table as you may fall and cause serious injury.
5. Please keep children out of the assembly area before assembly.



WARNING: Do not place heavy objects on the chair or table top.



WARNING: Weight limit is 250 lbs (113.39kg) for each seat.



WARNING: These chairs are heavy, and may require two adults for safe assembly.



CAUTION: Do not locate the product near any heat source.

Warranty

3 YEAR FRAME AND 3 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three years, and a three year limited warranty for the fabric.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.Hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



____ AA



____ BB



____ CC


Part	Description	Quantity
AA	Combination Bolt (1/4 in. x 0.669 in. L + 15° x 7° x 1.2T)	8+2
BB	Plastic Bolt Cap (1/4 in.)	8+2
CC	Allen Wrench (1/4 in.)	1

Pre-Assembly (continued)

CHAIR PACKAGE CONTENTS



IMPORTANT: DO not fully tighten bolts/screws until all pieces are loosely assembled.





Part	Description	Quantity
A	Seat Frame	2
B	Base Frame	2

Chair Assembly



1 ATTACHING THE BASE FRAME TO THE SEAT FRAME

- Attach the base frame (B) to the seat frame (A) using combination bolts (AA).



2 TIGHTENING THE BOLTS AND ADDING THE BOLT CAPS

- Once all of the bolts are in place, fully tighten the bolts using the allen wrench (CC).
- Install the bolt caps (BB) to every bolt.



Care and Cleaning

- ❑ For best result, clean the products with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- ❑ Do not clean with abrasive material, bleach, or solvents.
- ❑ Store the products in a dry, sheltered place when not in use.
- ❑ Keep the products away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

HAMPTON BAY®

**Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday**

1-800-841-1350

HAMPTONBAY.COM

Retain this manual for future use.


For certification use only
Chair ID # LG1259-3001

Item #1000 000 000
Model #LG1259-9PC-6PK

HAMPTON BAY[®]

USE AND CARE GUIDE

Crenshaw Park 6 -Pack Armless Dining Chairs



**Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday**

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of these dining chairs. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2	Pre-Assembly.....	3
Important Safety Instruction.....	2	Planning Assembly.....	3
Save These Instructions.....	2	Hardware Included.....	3
Read All Instructions Before Use.....	2	Chair Package Content.....	4
Warranty.....	3	Chair Assembly.....	5
What is Covered.....	3	Care and Cleaning.....	6
What is not Covered.....	3		

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: These chairs were made for the explicit purpose of providing outdoor functions and are not to be used as a toy. This product is intended for normal outdoor use; the manufacturer recommends storing and / or covering this set when any formidable / severe weather is approaching.



WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
2. Use this product only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Do not move the chair or table while they are occupied. Failure to obey this caution could result in injury.
4. Do not rock in the chair or table as you may fall and cause serious injury.
5. Please keep children out of the assembly area before assembly.



WARNING: Do not place heavy objects on the chair or table top.



WARNING: Weight limit is 250 lbs (113.39kg) for each seat.



CAUTION: Do not locate the product near any heat source.



WARNING: These chairs are heavy, and may require two adults for safe assembly.

Warranty

3 YEAR FRAME AND 3 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three years, and a three year limited warranty for the fabric.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.Hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.


HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



____ AA



____ BB



____ CC



____ DD


Part	Description	Quantity
AA	Combination Bolt (1/4 in. x 0.669 in. L + 15 Φ x7 Φ x1.2T)	12+2
BB	Combination Bolt (1/4 in. x 1.772 in. L + 15 Φ x7 Φ x1.2T)	6+2
CC	Plastic Bolt Cap (1/4 in.)	18+4
DD	Allen Wrench (1/4 in.)	2

Pre-Assembly (continued)

CHAIR PACKAGE CONTENTS



IMPORTANT: DO not fully tighten bolts/screws until all pieces are loosely assembled.



Part	Description	Quantity
A	Chair Frame	6
B	Seat Panel	6


Chair Assembly

1 ATTACHING THE SEAT PANEL TO THE CHAIR FRAME

- Attach the seat panel (B) to the chair frame (A) using combination bolts (AA) and combination bolt (BB).



NOTE: Please ensure all the bolts are assembled correctly and use the allen wrench (DD) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Add corresponding plastic bolt caps (CC) after final assembly is finished.




2 TIGHTENING THE BOLTS AND ADDING THE BOLT CAPS

- Once all of the bolts are in place, fully tighten the bolts using the allen wrench (CC).
- Install the bolt caps (BB) to every bolt.



NOTE: Please ensure all the bolts are assembled correctly and use the allen wrench (DD) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Add corresponding plastic bolt caps (CC) after final assembly is finished.



Care and Cleaning

- ❑ For best result, clean the products with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- ❑ Do not clean with abrasive material, bleach, or solvents.
- ❑ Store the products in a dry, sheltered place when not in use.
- ❑ Keep the products away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

HAMPTON BAY[®]

**Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday**

1-800-841-1350

HAMPTONBAY.COM

Retain this manual for future use.


For certification use only
Chair ID # LG1259-8401

Item #1000 000 000
Model #LG1259-9PC-TBL

HAMPTON BAY[®]

USE AND CARE GUIDE

Crenshaw Park Dining Table



**Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday**

**1-855-HD-HAMPTON
HAMPTONBAY.COM**

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this dining table. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2	Pre-Assembly.....	3
Important Safety Instruction.....	2	Planning Assembly.....	3
Save These Instructions.....	2	Hardware Included.....	3
Read All Instructions Before Use.....	2	Table Package Content.....	4
Warranty.....	3	Table Assembly.....	5
What is Covered.....	3	Care and Cleaning.....	7
What is not Covered.....	3		

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: This table was made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; the manufacturer recommends storing and / or covering this set when any formidable / severe weather is approaching.



WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
2. Use this product only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Do not move the chair or table while they are occupied. Failure to obey this caution could result in injury.
4. Do not rock in the chair or table as you may fall and cause serious injury.
5. Please keep children out of the assembly area before assembly.
6. This table is not intended to support an umbrella alone. Umbrellas shall always be used with a suitable base or stand.



WARNING: Do not place heavy objects on the chair or table top.



CAUTION: Do not locate the product near any heat source.



WARNING: This table is heavy, and may require two adults for safe assembly.

Warranty

3 YEAR FRAME AND 3 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three years, and a three year limited warranty for the fabric.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.Hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.




NOTE: More than one person may be required to assemble this product.


HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



____AA



____BB



____CC



____DD


Part	Description	Quantity
AA	Combination Bolt (1/4 in. x 0.591 in. L + 15 Φ x7 Φ x1.2T)	4+2
BB	Combination Bolt (1/4 in. x 0.984 in. L + 15 Φ x7 Φ x1.2T)	4+2
CC	Plastic Bolt Cap (1/4 in.)	8+4
DD	Wrench (1/4 in.)	1

Pre-Assembly (continued)

TABLE PACKAGE CONTENTS



IMPORTANT: DO not fully tighten bolts/screws until all pieces are loosely assembled.



Part	Description	Quantity
A	Table Top	1
B	Table Leg	2
C	Table Leg Connector	1
D	Umbrella Hole Cover	1


Table Assembly

1 ATTACHING THE TABLE LEGS TO THE TABLE TOP

- Attach the table legs (B) to the table top (A) using combination bolts (BB).



NOTE: Please ensure all the bolts are assembled correctly and use the wrench (DD) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Add corresponding plastic bolt caps (CC) after final assembly is finished.



2 ATTACHING THE TABLE LEG CONNECTOR TO THE TABLE LEGS

- Attach the table leg connector (C) to the table legs (B) using combination bolts (AA).
- Do not fully tighten all bolts at this step.



NOTE: Please ensure all the bolts are assembled correctly and use the wrench (DD) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Add corresponding plastic bolt caps (CC) after final assembly is finished.





Table Assembly (continued)

3 TIGHTENING THE BOLTS AND ADDING THE BOLT CAPS

- Once all of the bolts are in place, fully tighten the bolts using the wrench (DD).
- Install the bolt caps (CC) to every bolt.





NOTE: Please ensure all the bolts are assembled correctly and use the allen wrench (DD) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Add corresponding plastic bolt caps (CC) after final assembly is finished.



4 PUT THE UMBRELLA HOLE COVER ON

- Turn over the table and put the umbrella hole cover (D) in place.



Care and Cleaning

- ❑ For best result, clean the products with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- ❑ Do not clean with abrasive material, bleach, or solvents.
- ❑ Store the products in a dry, sheltered place when not in use.
- ❑ Keep the products away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

HAMPTON BAY®

**Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday**

1-800-841-1350

HAMPTONBAY.COM

Retain this manual for future use.

For certification use only
Table ID # LG1259-88XEU