




OPEN GENTLY




1



3



2



4

How to Set Up a Pop-Up Gazebo

Follow these instructions carefully to avoid hurting your hands or fingers while setting up the gazebo. It is important to have two people to assemble it.



Start by placing your Pop-Up Gazebo in the middle of the area where you want it to be. Take out the bag and stand the gazebo on its feet.

1. You and your partner should stand on opposite sides of the gazebo. Hold onto two outer legs and lift the frame slightly off the ground. Then, take a step backwards while keeping your arms fully stretched.
2. Each person should grab the top and bottom of the diamond-shaped area formed by the side supports on opposite sides. Push your hands together and continue stepping backwards until the shelter is fully opened. Be careful not to pinch your fingers or pull too hard, as this can cause the side supports to bend.
3. Engage the slider at each corner by pushing up with one hand while holding down the top of the leg with the other hand. A snap button will click into place. Repeat this step for the remaining three legs.
4. Both you and your partner should place a foot on the foot plate of the adjacent legs and lift up the leg. Slide the inner leg out until the snap button clicks into place. Repeat this step for the other two legs.
5. Make sure the Pop-Up Gazebo is properly aligned. Attach the velcro tabs, located on the underside of the top cover, around the frame struts.
6. To secure the gazebo to the ground, use the tie-down ropes attached to the ring at each corner of the roof cover, or simply insert stakes through the holes in each leg's foot.


CLOSE GENTLY




5



6



7



8

How to Take Down a Pop-Up Gazebo

Please note: It is important to be cautious when attempting to take down the gazebo in windy conditions, as it can be hazardous and may cause injury or damage to the product.

1. Start by removing any leg stakes and tie-down ropes. Undo the Velcro tabs that are holding the top cover around the frame.
2. Both you and your partner should lift up slightly on two adjacent outer legs. Depress the snap button and push the telescopic inner legs into the outer legs. Repeat this step for the remaining two legs.
3. Release the slider at all four corners by applying slight upward pressure with one hand while depressing the snap button with the other hand. Push the slider down past the snap button.
4. Each person should grab the top of the diamond-shaped area on opposite sides and lift it up slightly. Give the canopy a gentle shake. While stepping towards your partner, pull your hands apart until the unit is three-quarters closed.
5. Grasp the two outer legs, lift them slightly off the ground, and push them together to fully close the gazebo. Be careful not to pinch your fingers and avoid pushing too hard.

BE CAREFUL NOT TO PINCH FINGERS.

DO NOT PUSH HARD.

Please ensure that the base is properly secured. This gazebo should not be used in heavy rain or windy conditions, as it does not provide adequate shelter against adverse weather conditions.

Finally, once you have made sure that the canopy material is completely dry, return your Pop-Up Gazebo to its storage bag.