

# Guard-A-Latch

## Installation Instructions

### Doors Opening Out

*Puerta que abren hacia afuera*

Door  
(Puerta)



Fig. 1

### Doors Opening In

*Puerta que abren hacia adentro*

Jamb  
(Marco)

Strike Plate  
(Placa de Cerradura)



Fig. 2

Fig. 2A

Insert **Guard-A-Latch** between door and frame with door closed. If it is not too tight install on surface of door (for doors that open out, Fig.1) or on jamb (for doors opening in, Fig. 2). If it is too tight, remove some wood from the door or the jamb for a good fit.

1. For doors opening out: Install over strike plate with screws provided.
2. For doors opening in: Cut out a groove on jamb (Fig. 2-A), so **Guard A Latch** fits flush on jamb. Install over strike plate with screws provided.

### Instrucciones para Instalación

Ponga **Guard-A-Latch** entre la puerta y el marco con la puerta cerrada. Si no queda muy apretado, instalar en el lado de la puerta (para puertas que abren hacia afuera Fig.1) o en el marco (para puertas que abren hacia adentro, Fig.2). Si queda muy apretada, cortar un poco de madera de la puerta o del marco para que quede bien.

1. Para puertas que abren hacia afuera: Instale la unidad sobre la placa de la cerradura con los tornillos incluidos en el paquete.
2. Para puertas que abren hacia adentro: Cortar una canal en el marco de la puerta para que la unidad quede pareja con el marco (Fig.2-A). Instalar sobre la placa de la cerradura con los tornillos incluidos en el paquete.