atf-018l im（修改说明）-130x190mm-2024-10-30

USER MANUAL



Tower Air Cooler

MODEL NO.:ATF-018L

PLEASE READ THE SAFETY ADVICE CAREFULLY BEFORE USING THE APPLIANCE

⚠WARNING⚠

1. Use as per the rating voltage.
2. Do not repair or remake the appliance by yourself, it should be repaired by the repairmen.
3. Do not operate the appliance with wet hands, in order to avoid damage.
4. If the supply cord is damaged, it must be replaced by a same cord from the manufacturer or its service agents.
5. When the appliance is not in use, switch it off and unplug it.
6. Do not insert things to air outlets and inlets, in order to avoid damage.
7. Do not use the appliance near explosive and combustible gas.
8. Use the appliance only on a flat surface.
9. Do not use outdoors.
10. Do no turnover the appliance. Unplug the power supply if it is toppled over and there have some water in the body. Dry the body before use.
13.Clean the appearance with a lightly damp cloth.It can clean with neutral detergents. Do not rinse with water.
14.Do not make air outlets and inlets near the wall or curtain.
15.Do not knock or shake the body when use, otherwise it may cause stop.
17.The appliance must not located immediately below a socket outlet.

18.Do not use the appliance in the immediate surrounding of a bath,a show or a swimming pool.
19.This appliance is not intended for use by persons including children with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
20.Children should be supervised to ensure that they do not play with the appliance.

PRODUCT STRUCTURE



CONTROL PANEL



FUNCTIONS & OPERATION

1, Standby: insert the plug of the power cord into socket, products have a "dl". The product enters the standby state.
2, Turn on : Touch " ", the default wind speed is in middle speed and light up" ", digital tube display "2".
3, Wind speed: Touch speed key " ", products into wind speed regulating mode, the digital tube to "2-3-1-2....." order to switch, corresponding indicator light.
4, Mode : Touch mode key" " enter into nature wind " ", touch second, enter into sleep wind " ", touch again, enter into normal wind " ", then circulate in order
5, Timer: Touch timer key " ", the timing indicator light on " ~ ", the highest is 12h, each operation 1h' time adjustment.
5, Swing: Touch swing key " ",products into automatic swing function.at the same time, the swing indicator light on " ".

Touch this key again, the swing function off.
6, LIGHT ON/OFF: after 10 minutes of work, the product automatically turn off all lights, press any key to light the screen.
7, Cooling: Touch mode key" ", the water pump working, enter into cooling fuction. If you want cancel ,touch it again

REMOTE CONTROL



1. Before using the remote control: first unplug the plastic sheet at the lower end of the remote control, and the transmitter at the front of the remote control must be aligned with the receiving window on the product
2. Avoid direct sunlight exposure to the receiving window, so as not to affect the effect of the receiver.
3. If the remote control is not used for a long time, please take out the battery and dispose of it properly.
4. All operation in Remote control same as product's control panel.

BATTERY

The remote control use one button cells, model No. CR2025 (3V). We recommend the use of Lithium type battery for longer use.

Note: Please follow battery disposal instruction on battery packaging, or contact your local councils for safely disposal of batteries.

⚠WARNING

- **INGESTION HAZARD**: This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP NEW AND USED BATTERIES OUT OF REACH OF CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

*Remove and immediately recycle or dispose of used batteries according, to local regulations andkeep away from children. Do NOT dispose of batteries in household trash or incinerate.
*Even used batteries may cause severe injury or death.
*Call a local poison control center for treatment information.
*Replace the battery with 3 "CR2025" button cell battery and dispose of the used batteryproperly and in accordance with local law and ordinances.
*The nominal battery voltage of the "CR2025" button battery is 3.0V.
*Non-rechargeable batteries are not to be recharged.
*Do not force discharge, recharge, disassemble, heat above 70 °C (158°F) or incinerate. Doing sotmay result in injury due to venting, leakage or explosion resulting in chemical burns.
*Ensure the batteries are installed correctly according to polarity (+ and -).
*Do not mix old and new batteries, different brands or types of batteries, such as alkaline,carbon-zinc, or rechargeable batteries.
*Remove and immediately recycle or dispose of batteries from equipment not used for anextended period of time according to local regulations.
*Always completely secure the battery compartment. If the battery compartment does not closesecurely, stop using the product, remove the batteries, and keep them away from children.

ASSEMBLY



Turn the product upside down, take out the base, Angle the chassis to the buckle and fasten it (see P1&P2), align the fuselage with the buckle, rotate the fuselage and the base in the direction shown in the base installation diagram (see P3), and lock the product until you hear the buckle sound (see P4). To disassemble the base, please press (P5)

CLEANING AND MAINTENANCE

Clean with neutral detergent and soft cloth.
Attention: unplug the power plug when clean the appliance ,since there have high pressure in the body. Do not leave any water on the control panel.

ICE BOX USED

The ice crystal box has a unique cold storage and insulation characteristics, which can slowly absorb the heat in the water, so that the water temperature in the tank is lower than the ambient temperature, and the wind blown by the cold fan is cooler.
How to use:
1) Unscrew the bottle cap and add water to near the highest water level (note that the water should not exceed the highest water level).
Note: The ice crystal raw materials in the ice crystal box are forbidden to eat.
2) Add water to the removed ice crystal box, tighten the cap, and refrigerate until the ice crystal box is completely frozen.
3) Put the frozen ice crystal box into the upper tank or the bottom tank.
4) The product is equipped with multiple ice crystal boxes, which can ensure continuous use.

CUSTOMER SERVICE
CONTACT OUR PROFESSIONAL CUSTOMER SUPPORT AT
lezihai0425@outlook.com