

## ZERO GRAVITY CHAIR

# StyleWell.™


ITEM #1004 432 283  
MODEL #CHARLES-20RB

## Use and Care Guide

### Operation

#### 1 USING THE ZERO GRAVITY CHAIR

- Always place the zero gravity chair on a hard, level surface.



### Safety Information



**WARNING:** Never use this product as a support. Do not shake, lean, or climb on the product at any time.



**WARNING:** The weight limit for this chair is 225 lbs (102.05 kg).

### Care and Cleaning

- For best results, clean the frame with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach, or solvents.
- Store the chair in a dry, sheltered place when not in use.
- Keep the chair away from fire, extreme heat, freezing conditions, and inclement weather such as rain, sleet, snow, or wind.

### Warranty

#### 1 YEAR FRAME AND 1 YEAR FABRIC LIMITED WARRANTY

##### WHAT IS COVERED

We warrant the frame and fabric to be free of manufacturing defects to the original purchaser for one year.

##### WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-877-527-0313 or visit [www.HomeDepot.com](http://www.HomeDepot.com).