



# How To Measure Panel Lengths

Panel Length = 




Before measuring, remove the endcaps as shown.

Panel Length =



-3"

Panel Length =



-3"



Before measuring, remove the endcaps as shown.