








INSTRUCTION MANUAL









If you have any problem.

E-mail us at customerservice@veikous.com














HARDWARE

A  37PCS	B  37PCS	C  8 x 30mm 32PCS	D  4 x 10mm 2PCS	E  4 x 18mm 4PCS	F  4PCS	
G  4 x 12mm 2PCS	H  4 x 35mm 23PCS	I  4 x 65mm 10PCS	J  3 x 12mm 6PCS	K  4 x 14mm 48PCS	L  8PCS	
M  2PCS	N  8PCS	O  2PCS	P  2PCS	Q  4PCS	R  4 x 12mm 4PCS	S  2PCS




PARTS

1  1PC	2  1PC	3  1PC	4  1PC	5  1PC	6  4PCS
7  1PC	8  1PC	9  1PC	10  1PC	11  1PC	12  1PC




PARTS

13  1PC	14  1PC	15  1PC	16  1PC	17  1PC	18  2PCS
19  1PC	20  1PC	21  1PC	22  1PC	23  1PC	24  1PC
25  1PC	26  1PC	27  1PC	28  1PC	29  1PC	30  1PC
31  2PCS	32  2PCS				



STEP 1





STEP 2





STEP 3





STEP 4





STEP 5




STEP 6





STEP 7




STEP 8





STEP 9




Please install the screws into the correct holes based on the instructions.





STEP 10



STEP 11




STEP 12



STEP 13




B x 2




STEP 14



B x 2




STEP 15





C x 8




I x 10





STEP 16




STEP 17



STEP 18




STEP 19




STEP 20

	R x 4		S x 2
--	-------	--	-------




STEP 21

	D x 2
---	-------





STEP 22

	N x 8
---	-------




STEP 23

	E x 4		F x 4		K x 16		L x 8
--	-------	--	-------	--	--------	--	-------




STEP 24


	K x 32		Q x 4
--	--------	--	-------





If you want to adjust the height of door to align it horizontally, please try the step a to let the door move up and down.



If you want to adjust the distance between the doors, please try the step b to let the door move right and left.








If you want to adjust the relative depth of the door, please try the step c to let the door back and forth.




STEP 25

	H x 2		P x 2
---	-------	---	-------



ENJOY YOUR PRODUCT!



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.