



PressureWave™

DRAWDOWN & SIZING CHART

Vertical



Tank drawdown and sizing chart Tabla de desplazamiento por volumen Tableau capacité utile du réservoir								
	VOLUME		20/40		30/50		40/60	
	gallon	liter	gallon	liter	gallon	liter	gallon	liter
PWN-US-80LV	21.1	80	7.72	29.25	6.53	24.73	5.65	21.42
PWN-US-130LV	34.3	130	12.52	47.58	10.57	40.17	9.17	34.84
PWN-US-160LV	42.3	160	15.48	58.60	13.07	49.48	11.34	42.91

Horizontal



Tank drawdown and sizing chart Tabla de desplazamiento por volumen Tableau capacité utile du réservoir								
	VOLUME		20/40		30/50		40/60	
	gallon	liter	gallon	liter	gallon	liter	gallon	liter
PWN-US-24LH	6.3	24	2.32	8.78	1.96	7.42	1.70	6.43
PWN-US-60LH	15.9	60	5.79	21.94	4.90	18.55	4.24	16.06
PWN-US-80LH	21.1	80	7.72	29.25	6.53	24.73	5.65	21.42

Inline



Tank drawdown and sizing chart Tabla de desplazamiento por volumen Tableau capacité utile du réservoir								
	VOLUME		20/40		30/50		40/60	
	gallon	liter	gallon	liter	gallon	liter	gallon	liter
PWN-US-8LX	2.1	8	0.77	2.93	0.65	2.47	0.57	2.14
PWN-US-18LX	4.8	18	1.74	6.58	1.47	5.56	1.27	4.82
PWN-US-35LX	9.3	35	3.38	12.80	2.86	10.82	2.47	9.37

Where Water Gets Better

HAVE QUESTIONS OR NEED ASSISTANCE? CONTACT US TODAY