Use & Care Manual

Installation:

1. Before installation, inspect the wheelbarrow axle to ensure it is clean and free from debris.
2. Carefully slide the flat-free tire onto the axle, ensuring that it is centered and securely seated.
3. If necessary, use appropriate tools to tighten any fasteners or bolts to secure the tire in place.
4. Double-check that the tire is properly aligned and rotates smoothly before use.

Usage:

1. These flat-free tires are designed to withstand various terrains and conditions, including gravel, concrete, and uneven surfaces.
2. Avoid overloading the wheelbarrow beyond its recommended weight capacity, as this may affect performance and safety.
3. When transporting heavy loads, distribute the weight evenly to prevent excessive strain on the tires and axle. Exercise caution when navigating sharp turns or rough terrain to minimize the risk of damage to the tire or wheelbarrow.

Maintenance:

1. Regularly inspect the tires for signs of wear, damage, or punctures. If any issues are detected, discontinue use and replace the tire promptly.
2. Clean the tires periodically with mild soap and water to remove dirt, grime, and debris that may accumulate during use.
3. Check the tire pressure periodically using a pressure gauge to ensure it remains within the recommended range.
4. Lubricate any moving parts, such as bearings or axles , according to the manufacturer's recommendations to maintain smooth operation.

Storage:

1. When not in use, store the wheelbarrow in a clean, dry, and sheltered location to protect it from the elements.
2. If storing the wheelbarrow for an extended period, consider elevating it off the ground to prevent flat spots from forming on the tires.
3. Cover the wheelbarrow with a tarp or protective cover to shield it from dust, moisture, and sunlight.