


Please read all instructions before proceeding. Always wear protective eye wear when assembling.

For residential applications, single walk gates are generally used for people to pass through. These walk gates are easy to install and provide you with the security needed for your residence when included as part of your chain link fence. Walk gates are constructed with 12.5 gauge, 11.5 gauge, or 9 gauge galvanized fabric. The framework and fittings are also constructed from galvanized steel for long life.

Walk gates are single panel gates that hinge from one terminal post (also referred to as gate post) and latch to another. Walk gates are installed at the same height as the chain link fence. These instructions will assist you with installation of a single panel walk gate.



Step 1: Before you Begin

Note that there are two key measurements to consider; the gate measured width [1], and the gate measured opening [2]. These will differ by four inches. The gate measured width is the length measured from outside of gate frame work. The gate opening, is the length measured from the inside of the terminal/gate posts. The gate width should measure four inches shorter than the gate opening to allow for mounting hardware and gate latch.

Step 2: Install the Gate Posts

NOTE: if the gate posts are already installed, measure the length of the gate opening [2]. Purchase a gate with an actual gate width measurement four inches less than the gate opening.

Measure the gate width.

Install the gate posts so that the length between the inside of the posts is four inches greater than the gate width. Gate posts are installed in cement, approximately two feet into the ground. Gate posts should be installed so that they are two inches higher than the top of the gate. Allow the gate post cement to dry [3].

Step 3: Install the Hinges

Install the post hinges on one gate post. The top post hinge will point down, the bottom post hinge will point up [4].

Install the gate hinges on one side of the gate. Do not tighten. Slide the gate hinges over the post hinges. Ensure that the top of the gate is in line with the top of the chain link fence [5]. Tighten the gate hinges in place. The gate should swing freely.

Step 4: Install the Gate Latch

Install the gate latch on the other side of the gate to complete the installation [6].