

Use and Care Manual

I. Instructions for use:

Moving the cart: Hold the handle of the Folding Garden Shopping Beach Cart, place your other hand under the wheel, and gently pull the cart away. If you need to move more easily, you can gently push the handle of the cart and use the rolling motion of the wheel to move the cart.

Adjusting the handle height: If you need to adjust the handle height, you can hold the handle and gently adjust it up or down to accommodate different user heights.

Folding and storage: When it is necessary to fold and store the bike, first loosen the brake device on the wheel, then fold the handlebar, and finally fold the entire bike into a size suitable for storage.

II. Maintenance Instructions:

Regular cleaning: Use a damp cloth to wipe the surface of the car to remove dust and dirt. Avoid using cleaning agents containing chemicals.

Avoid scratching: Avoid placing the Folding Garden Shopping Beach Cart next to sharp objects or being scratched by the outside world.

Protect from sun and moisture: Long-term exposure to sunlight or a humid environment may damage the car. Therefore, store it in a cool, ventilated place and avoid prolonged exposure to sunlight or a humid environment.

Regular inspection: Regularly check the fasteners, wheel bearings, and other parts of the Folding Garden Shopping Beach Cart for firmness and reliability. If there are signs of damage or loosening, please repair or replace them in a timely manner.

Avoid heavy pressure: Do not place heavy objects inside the box to avoid excessive pressure on the car.

Wheel maintenance: Regularly check the wheel bearings and wheels for tightness. If signs of loosening or damage are found, please adjust or replace them in a timely manner. When folding and storing the car, make sure that the braking device on the wheel has been released to avoid damage to the wheel.