


Assembly Instructions

Caution: You must read this before you proceed




**Please look underneath Seat panel of the Loveseat
for hardware packs.**

TABLE





Caution: This Table is NOT a TOY. Keep your child / children at bay during the assembly process. For moving the Table and to prevent damage to the Table, two adults are needed to execute this action.

Parts List


Label	Picture	Description	QTY
A		Table Top	1
B		Leg Panel	2
C		Support Bar	1

Hardware

Label	Picture	Description	QTY
①		Screw (M7x70mm)	7
②		Allen Key	1

Assembly Preparation

Before Beginning Assembly:





- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-



- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Before Beginning Assembly:

OVERVIEW

Table Top (A)

Leg Panel (B)


Support Bar (C)



FRONT FACING


This Table has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.

Step 2




Lay down the Table Top (A) with its underside facing skywards onto a clean, soft surface to avoid any scratch or damage to the product.

2.1) Put the tenon of Table Top (A) into the mortise of Leg Panel (B) and then using Screw (①) with Allen Key (②) to secure these parts as shown in above picture.

2.2) Repeat the same process with the remained Leg Panel (B).

Do not fully tighten the Screws.

Step 3




Put the tenon of Support Bar (C) onto the mortise of Leg Panels (B) and then using Screw (①) with Allen Key (②) to secure these parts as shown in above picture.

You may need to push the Leg Panels (B), outwards, slightly to attach the Support Bar (C).

Do not fully tighten the Screws.

Step 4



Stand the Table up, with assistance from your adult partner.
Exert pressure floorwards, onto the Table with both your hands.
This pressure will help the Legs and Table Top reach full alignment status.
Check for wobbles on a LEVEL surface.
If no wobbles are found proceed to tighten the Screws in a sequential manner, until evenly secured.










When tightening the Screws tighten sequentially.

**Do not tighten any Screw fully and then move on towards the next one.
If there are still wobbles, loosen the Screws and excute the same
above process.**

Your Table is ready for use.

This Table can only be used on the flat, level surface.

Care & Maintenance

- ⊘  ● Do not put hot items directly on furniture surface.
 - ⊘  ● Do not clean furniture with harsh cleansers or polish.
 - ✓  ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 - ⊘  ● Children should not climb or jump on the furniture.
 - ⊘  ● Do not write on furniture without a padded barrier to protect the surface.
 - ✓  ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 - ⊘  ● Not for commercial use. For residential use only.
 - ⊘  ● Stains may be removed with mild soap solution and damp cloth.
 - ✓  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .
-